



NATIONWIDE ELD
APP USER MANUAL FOR DRIVERS



Revision Table

Revision No	Date	Release Description	Author
0	04/01/20	Android - App User Manual	NationWide ELD Team



CONTENTS


1. LOGIN CREDENTIALS	3
1.1 Enter login credential	3
1.2 Forgot password	4
2. Home Page	6
2.1 App's Dashboard	6
2.1.1 VIN Selection	7
2.1.2 Mode of driving	7
2.1.3 How to select Duty of Status	9
2.1.4 Vehicle status	10
3. MENU PAGE	11
4. Driver Duty Limitation	12
5. VIOLATION STATUS	13
5.1. Continuous Hours	14
5.2 Driving Hours	15
5.3 Duty Hours	16
5.4 Weekly Hours	17
5.5 Violation Icon Behaviour	18
6. SELF-INSPECT MENU	19
6.1 Status Logs	19
6.2 EDIT STATUS LOGS	20
7. SELF-CERTIFIED MENU	21
8. REPORT MENU	24
9. TRIP/LOAD SHEET MENU	25
9.1 Add Load Sheet	25
9.2 Add Consignment	26
10. FUEL PURCHASE	29
11. DVIR MENU	30
11.1. Pre-Trip	31
11.2. Post-Trip	34
11.3. GET LIST	35
12. SIGN-OUT & SIGN-IN PAGE	37
13. Log Report	38
14. EXCEPTION	40
15. ABOUT ELD PAGE	41
16. APP QUICK HOW - TO'S	42



1. LOGIN CREDENTIALS

1.1 Enter login credentials

- Make sure mobile data is on.
- Enter your Driver ID (A 4-6-digit number that was generated by the back office dashboard when the driver's profile was created).
- Enter your password. It will not be displayed. To display the entered password, click on .
- To automatically display the password next time you login, check the Remember Me check box.
- Click on the Sign In button.



After app installation, If the driver has logged in and logged out once, next time the login page will be displayed as an unidentified profile. In Unidentified Profile also you can follow the same process to Login.



1.2 Forgot password

- a. Click on **Forgot Password?** link to generate a new password.
- f. Password reset can be done by giving **driver id, license no and license expiration date.**
- g. Set a new password alert is seen.
- h. Once you have reset; login to your account.
- i. Password successful pop-up is displayed.


The screenshot shows the 'Forgot Password' screen in the Nationwide ELD mobile application. At the top, the Nationwide ELD logo is displayed against a blue sky background. Below the logo, a grey semi-transparent form overlay is positioned over a background image of a road. The form contains the following elements:

- A 'Driver ID' label with a person icon and a text input field.
- A label 'Enter License Number or Expiry Date' above a 'Licence Number' input field with a document icon.
- A label 'Date: MM/DD/YYYY' with a calendar icon and a date input field.
- Three navigation buttons at the bottom: '← BACK', '↻ CLEAR', and '→ NEXT'.




2. Home Page

Once you login you will be on the app home page. In the upper right corner click Connect to Device.



The app will sync with the ELD and the home page will look as shown below. The VIN number will be displayed in green text above the date and ELD name is displayed below the date.




2.1 Apps Dashboard

- On the left-hand side driver's name, business name, trip no and start location/ trip origin are displayed.
- On the right-hand side VIN no, date and ELD no. is displayed in green.
- Balance driving hours for the day displayed on the left and Balance Duty hours for the week on the right respectively.



2.1.1 VIN Selection


In Some cases trucks may not stream the VIN. In order to resolve this,




- Login into Nation Wide ELD website.
- In the dashboard from the left menu click "My fleet".
- Click "Add Fleet" pop up screen opens.
- Please fill in the VIN, Plate number and Truck no and click "Save".
- Continue steps a-d, if you have more than one truck.
- Now when you login from the APP, when the VIN is not streamed, you will get a pop up, listing the truck numbers (the information we have added in "My fleet").
- Select the truck number.
- Now the App will bind the VIN to the SSID, so that VIN will be a part of the data stream from the truck.

2.1.2 Mode of driving


- In the ELD Dashboard screen, click to select the Driver mode of driving.
- In the Mode of driving Strip, select Default to access all the duty status (off duty, Sleeper Berth, Driving, On duty, Waiting Time).
- Once the Driving Mode has been selected, you can select the duty of driving accordingly. The Comments dialog box appears.



- d. Enter your comments and click on the Submit button to record your comments. If you do not want to record your comments, click on the skip button.
- e. You can view the following Event Comments popup for Personal Use.



- f. You can view the following Event Comments popup for Yard Moves.




- g. The selected Driver mode is displayed on the ELD Dashboard.
- h. You can select the same as to change Driving mode to PERSONAL USE and YARD MOVES.

	<p>The following categories are available:</p> <ul style="list-style-type: none"> Default – Select for on duty driving Personal Use – Select for personal use Yard Moves – Select for yard shuttle service
	<p>If you select Default, the Duty of Status dialog box is enabled. You can choose an appropriate option based on the driving situation.</p>

2.1.3 How to select Duty of Status



- a. Click on the appropriate Duty of Status.
- b. The selected Duty of Status is displayed on the ELD Dashboard.



- c. You can view the following Event Comments popup for On Duty Not Driving duty status.



TIA

JUSTIN

Triesten Technologies

Connect to ELD

03-Apr-2020:03:13:02

Event Comments

Enter your comments for
Duty Status: On Duty Not Driving

Pre-Trip Post-Trip

Loading Unloading

Hooking Dropping

Repairing DOT Inspection

Fueling Border Crossing

Event comments must be 4-60 characters.

Event Comments

CANCEL SKIP SUBMIT

— Synced Event logs — Un-synced Event logs

2.1.3 Vehicle status

For example, if your duty status is in driving, but the vehicle is idle more than 5 minutes, the vehicle status displays a pop up message to suggest you to change your driving status.

Duty Status change request

CMV has not been in-motion for 5 minutes

→ Change to Not Driving

→ Continue Driving

Closes in 59




3. MENU PAGE

Menu page contains all the app features like Notifications, Load Sheet, DVIR, Fuel Purchase, Log Report, Exception.


For example, if you are entering Load sheet details and if you want to move to DVIR, you can select the Menu icon on the top left and you can easily navigate to different features in the App.

Once you are done with your driving service you can sign out of the app by clicking the Sign out from the top left menu icon.






4. Driver Duty Limitation



Your Driver Duty Limitation status is located in the top left most icon, which reflects the type of driving you selected from the website for that particular driver. There are currently 12 types of driving limitations. You can switch to Canada rule from default rule by using switch option from Settings on the left side menu.





- d. **US 7 Days 60 Hours:** It is the rule of driving 60 hours a week which you selected from the Nation Wide ELD website.
- e. **US 8 Days 70 Hours:** It is the rule of driving 70 hours a week which you selected from the Nation Wide ELD website.
- f. **100 Air Miles:** Rule indicates that the driver is driving within 100 mile radius of their yard or main office.
- g. **150 Air Miles:** Rule indicates that the driver is driving within 100 mile radius of their yard or main office.
- h. **Construction Material 7 Days 60 Hours:** Rule indicates that the driver is driving 60 hours a week for the vehicles which are used for construction work/purpose.
- i. **Construction Material 8 Days 70 Hours:** Rule indicates that the driver is driving 70 hours a week for the vehicles which are used for construction work/purpose.
- j. **Groundwater 7 Days 60 Hours**
- k. **Groundwater 8 Days 70 Hours**
- l. **Passenger 8 Days 70 Hours**
- m. **Passenger 7 Days 60 Hours**
- n. **Canada 7Days 60 Hours**
- o. **Canada 14Days 120Hours**

5. VIOLATION STATUS

You can view your violation status via the four primary sub icons located in the top row of the app.






5.1 Continuous Hours

The rule of Continuous hours will depend upon the duty of driving which you selected for the driver during creation of driver ID from the Nation Wide ELD website.


- Hours spent:** Summary of total continuous hours driven per day.
- Max Hours:** As per the rule of continuous driving is allowed on the basis of duty of limitation which you select.
- Violated Hours:** Shows the number of hours driven more than the rules.





5.2 Driving Hours

The rule of Driving hours will depend upon the duty of driving which you selected for the driver during creation of driver ID from the Nation Wide ELD website.




- d. **Hours Spent:** Summary of total driving hours per day.
- e. **Max Hours:** As per the rule of driving is hours allowed on the basis of duty of limitation which you select.
- f. **Violated hours:** Shows the number of hours driven more than the rule.



5.2 Duty Hours

The rule of Duty hours will depend upon the duty of driving and on duty hours which you selected for the driver during creation of driver ID from the Nation Wide ELD website.




- g. **Hours Spent:** Summary of total driving and on duty hours per day.
- h. **Max Hours:** As per the rule of duty hours is allowed on the basis of duty of limitation which you select.
- i. **Violated hours:** Shows the number of hours driven more than the rule.



5.2 Weekly Hours

The rule of Weekly hours will depend upon the duty of driving which you selected for the driver during creation of driver ID from the Nation Wide ELD website.



- j. **Hours Spent:** Summary of total driving and on duty hours for the week.
- k. **Max Hours:** As per the rule of weekly hours is allowed on the basis of duty of limitation which you select.
- l. **Violated hours:** It shows the number of hours driven more than the rule.



5.2 Violation Icon Behaviour



Green Icon represents your current Continuous Hours, Driving Hours, Duty Hours and Weekly Hours under non – violation status.



Orange Icon represents your current Continuous Hours, Driving Hours, Duty hours and Weekly Hours about to be in violation status i.e. the icon colour will change to orange before 30 Mins.




Red Icon represents your current Continuous Hours, Driving Hours, Duty Hours and Weekly Hours exceeded the hours limitations and you have violated the hours.




6. SELF-INSPECT MENU

The dashboard of the Self Inspection page contains Driver name, Truck VIN details, Date, ELD details, Company name, Trip number, origin, and destination.




6.1 Status Logs

- a. **STATUS LOG:** By selecting the status log button, it displays **Duty status logs** of the driver on the present day.



6.2 Edit Status Logs

If you click an event, you will get the option to edit the logs. Once you click the Edit button, you can view the Duty Status button to change the status of driving such as Off Duty, Sleeper Berth, Driving and On Duty Not Driving. Select the option which you want to change or edit accordingly.






7. SELF-CERTIFIED MENU

The dashboard of the Certify page contains Driver name, Truck VIN details, Date, ELD details, Company name, Trip number, origin, and destination.


Certify primarily contains PENDING and CERTIFIED details.




- a. **PENDING:** When you select the pending button, it displays the message which indicates the particular self-certified items for a specified date that were not completed.

For **example**, if you did not self-certify for a particular date, you can click on that date which is shown by the app and you can certify it by entering comments and certifying. Then it will reflect in the certified menu.

After entering comments for a particular Pending self certified record, You can view that under the Certified button.



- b. **CERTIFIED:** By selecting the "Certified" button, it displays the dates which you already self-certified. You can also edit the previously certified data, but your "Resubmission" count will increment when you edit your self-certified data again.





TIA

JUSTIN Connect to ELD

Triesten Technologies 03-Apr-2020:04:05:25

Trip No: Trip not started

Self Certification

Self Certification

Event Comments

testing

I hereby certify that my data entries and my record of duty status for this 24-hour period are true and correct

NOT READY **CERTIFY**

Dec 7, 2019

Dec 8, 2019

Dec 9, 2019



8. REPORT MENU

The dashboard of the Report page contains Driver name, Truck VIN details, Date, ELD details, Company name, Trip number, origin, and destination.

The screenshot shows a mobile application interface for a 'Report Menu'. At the top, there is a 'Dashboard' header with a hamburger menu icon and the 'NATIONWIDE ELD' logo. Below the header is a 'TIA' section with four icons: a person, a truck, a location pin, and a calendar. The main content area displays the driver's name 'JUSTIN' and a 'Connect to ELD' button. Below this, the company name 'Triesten Technologies' and a timestamp '03-Apr-2020:04:03:53' are shown. A red text label indicates 'Trip No: Trip not started'. A 'Roadside Inspection' section includes a checked checkbox icon and two buttons: 'WEB' (which is highlighted) and 'EMAIL'. Below these buttons, the date 'Date : 04-04-2020' and time 'Time : 02:33 am' are displayed, along with 'Latitude :10.645' and 'Longitude :77.4796133'. A 'Comments' field is present with a 'SEND' button below it. At the bottom, there is a navigation bar with four icons: a home icon, a pencil icon, a magnifying glass icon, and a list icon.

This screenshot is identical to the one on the left, showing the same 'Report Menu' dashboard. The only difference is that the 'EMAIL' button is now selected and highlighted, while the 'WEB' button is no longer highlighted. All other elements, including the driver name 'JUSTIN', company name 'Triesten Technologies', timestamp, trip status, inspection details, and navigation bar, remain the same.


We have 2 ways of submitting logs to FMCSA via WEB and EMAIL by selecting either one of them, fill the Location description and comments and then click send button.

In the comments field driver need to input the Inspection Code in-order to send the report to FMCSA. This code will be provided by the DOT Road Patrol Officer.



9. TRIP/LOAD SHEET MENU

You can create your load sheet by using the **Nation Wide ELD website** or **Nation Wide ELD App**.



9.1 Add Load Sheet

After clicking Add Load Sheet the next screen opens where you can add your load information such as Date, Origin, Destination, Driver (you can add co-driver) and Trailer number.

Note: You can add your co- driver if required or you can leave it blank.



Load Sheet Form ADVANCED

Load Number

Truck Number Trailer Number

Consignee/BL

Odometer Reading in KM

Origin Destination

Select a Cou.. Select a Cou..

City City

Date : Tap to Choose

Co Driver: Choose a Co-Driver if applic..

Cancel Save

9.1 Add Consignment

- a. By clicking the Plus button(+), it will proceed to the next screen where you need to fill **shipper details**.

Shipper Info

Select Shipper +

Address :

City : Zip Code :

State : Country :

Cancel Save



To **Add Shipper Details**: Enter Shipper name, Country, Zip Code, City and Address. Click Save to proceed.

The screenshot shows the 'Load Sheet' app interface. At the top, there is a menu icon, the Nationwide ELD logo, and the title 'Load Sheet'. Below this, the 'Shipper's Name' section is visible, containing a text input field for the shipper's name, a dropdown menu labeled 'Select a Cou..', and text input fields for 'Zip Code', 'City', and 'Address'. At the bottom of the screen, there are two buttons: a red 'Cancel' button and a white 'Save' button.

Note: You can't edit Shipper details once you have saved via App but you can edit through Nation Wide ELD website.

- b. **Consignment Info:** Here enter consignment details such as Billing date, Description, Packing type, Quantity, Weight, Delivery notes and P.O Number.

The screenshot shows the 'Load Sheet' app interface with the 'Consignment Info' section expanded. A red arrow points to the 'Consignment Info:' header. The section includes a 'B/L Date: Tap to Choose' field, a 'B/L' field, a 'P.O Number' field, a 'Commodity' field, a 'Select Packa..' dropdown menu, a 'Quantity' field, a 'WEIGHT IN LBS' dropdown menu, a 'Weight' field, a 'Delivery Notes' text area, a 'Consignee Info' section with a 'Consignee Name' field and an 'Address' field, and a 'Select a Cou..' dropdown menu. At the bottom, there are 'Cancel' and 'Save' buttons.



- c. **Consignee Info:** Here enter consignee details such as Consignee Name, Address, Country, City, State and Zip Code.

Consignee Info

Consignee Name

Address

Select a Cou..

Cancel Save

After filling above load sheet information click the save button. The Load Sheet information will be available inside the Load Sheet Dashboard.

You can create multiple Load Sheets and you can select the required Load Sheet according to the trip.

Once you select the required Load Sheet you can Edit or Use the Load Sheet. When you Use the Load Sheet your Load information is on the **main home dashboard** where you can track your trip.

Load Sheet List + NEW

Trip No : 1234655 Consignment Nos.: 0
Date : 04/24/20 00:00 - null
Origin: Testsg, DURANGO, MX
Destination : Hsjsiud, HAWAII, US

Load Sheet

Trip No: 1234655 Date : 04/24/2020
Org : Testsg, DURANGO, MX 05:30:00
Dest : Hsjsiud, HAWAII, US

Do you wish to start the trip?

Yes No

OR

Edit



Once you are done with your trip you can select the respective Load Sheet and you can **close the Current Trip** by clicking **"Yes"**.

10. FUEL PURCHASE

- Fuel Type → Select your fuel type from dropdown.
- Gallons / Litres → Enter the Gallons / Litres purchased.
- Amount → Enter the Gallons / Litres amount.
- Capture Bill → You can take a picture of your Fuel Receipt and our app saves it.

☰  Fuel Purchase

 Fuel Purchase

Device Date : 04-05-2020 Time : 04:21 am
Home Terminal Date : 04-04-2020 Time : 05:51 pm
Latitude : 10.6447326 Longitude : 77.4794295

Gallons Litres

Quantity Amount

Fuel Type : A55 Truck...


 Tap the icon to capture bill

SAVE



11. DVIR Menu

Driver Vehicle Inspection Report (DVIR) primarily contains "Pre/Post" and "Get List".





11.1 Pre-Trip

Pre-trip is a mandatory report which needs to be checked and signed before you begin your trip.

The screenshot shows a mobile application interface for a DVIR (Driver Vehicle Inspection Report) form. The title bar at the top says 'DVIR'. Below it, the form is titled 'DVIR Form'. There are two radio buttons: 'Pre-Trip' (selected) and 'Post-Trip'. A checkbox for 'C-TPAT' is present and unchecked. The form contains the following fields and text:

- Carrier : Triesten Technologies
- Address : Interchange Dr.
- Truck No. : 113
- Truck VIN :45VHJ293R29RH7654321
- Truck Plate No. :113
- Date : Choose Date
- Odometer Reading in KM
- Trailer No. (with a plus sign icon to add more)
- Defect Status
 - CONDITION OF THE ABOVE VEHICLE IS SATISFACTORY
 - ABOVE DEFECTS CORRECTED
 - ABOVE DEFECTS NEED NOT TO BE CORRECTED FOR SAFE OPERATION OF VEHICLE
- Remarks

At the bottom, there is a red circular button with a white eye icon. Below it, the text reads: 'Inspection Conducted by Justin Mark I, Justin Mark, declare that the vehicle(s) list (have) been inspected in accordance with SCHEDULE 1.'

- By clicking the Pre/Post button, it will ask you to submit a pre-trip report, where you can find the carrier name, address, date, time, Truck number, VIN, Plate No, Location Comments and odometer reading (it will reflect current odometer reading automatically).
- You are required to manually enter the trailer number.
- The **accessories list** contains 22 mandatory individual items to check during pre-trip. You can add additional accessories using the Nation Wide ELD website.



☐ Air Brake System

Minor Defects:

- ☐ AUDIBLE AIR LEAK
- ☐ SLOW AIR PRESSURE BUILD-UP RATE

Major Defects:

- ☐ PUSHROAD STROKE OF ANY BRAKE EXCEEDS THE ADJUSTMENT LIMIT
- ☐ AIR LOSS RATE EXCEEDS PRESCRIBED LIMIT
- ☐ INOPERATIVE TOWING VEHICLE PROTECTION SYSTEM

☐ Cab

Minor Defects:

- ☐ OCCUPANT COMPARTMENT DOOR FAILS TO OPEN

Major Defects:

- ☐ ANY CAB OR SLEEPER DOOR FAILS TO CLOSE SECURELY

☐ Cargo Securement

Minor Defects:

- ☐ INSECURE OR IMPROPER LOAD COVERING
- ☐ INSECURE CARGO

Major Defects:

- ☐ ABSENCE FAILURE MALFUNCTION OF DETERIORATION OF REQUIRED CARGO SECUREMENT DEVICE OR LOAD COVERING

Tractor

- ☐ Bumper/Tires/Rims
- ☐ Doors/ Tools compartments
- ☐ Battery Box/Air breather
- ☐ Fuel Tanks/interior Cab
- ☐ Compartments/sleeper
- ☐ Faring / Roof

Trailer

- ☐ Rear Bumper
- ☐ Doors / Floor
- ☐ Exterior- Front / Sides
- ☐ 5th wheel Area
- ☐ Check natural compartments
- ☐ Skid Plate

Trailer cont'd

- ☐ Front Wall / Left side /Left side
- ☐ ceiling / Roof Inside & outside
- ☐ Doors Outside/ undercarriage
- ☐ ABS Light

Defect Status

- In the **Defect status**, you have to select any one of the three radio buttons which are suitable and you have to add your comments (entering comments is mandatory) under the **Remarks field**. Finally, the driver has to **sign and save**.
- Once the required pre-trip details have been entered and saved the data is reflected in the DVIR dashboard/page and the driver can view it on the same page.



☰  DVIR

← **DVIR Form**

Address : Interchange Dr.
Truck No. : 113
Truck VIN :45VHJ293R29RH7654321
Truck Plate No. :113

Date : Choose Date

Odometer Reading in KM

Trailer No. +

Defect Status

CONDITION OF THE ABOVE VEHICLE IS SATISFACTORY

ABOVE DEFECTS CORRECTED

ABOVE DEFECTS NEED NOT TO BE CORRECTED FOR SAFE OPERATION OF VEHICLE

Remarks

Inspection Conducted by Justin Mark
I, Justin Mark, declare that the vehicle(s) listed has (have) been inspected in accordance with SCHEDULE1.



UPDATE DRIVER SIGN

Accessory 

SUBMIT



11.2 Post-Trip

Post-trip is a mandatory report checked and signed after reaching the destination.

☰ DVIR

← DVIR Form

Pre-Trip Post-Trip

C-TPAT

Carrier : Triesten Technologies
Address : Interchange Dr.
Truck No. : 113
Truck VIN :45VHJ293R29RH7654321
Truck Plate No. :113

Date : Choose Date

Odometer Reading in KM

Trailer No. +

Defect Status

CONDITION OF THE ABOVE VEHICLE IS SATISFACTORY

ABOVE DEFECTS CORRECTED

ABOVE DEFECTS NEED NOT TO BE CORRECTED FOR SAFE OPERATION OF VEHICLE

Remarks


Inspection Conducted by Justin Mark
I, Justin Mark, declare that the vehicle(s) list
(have) been inspected in accordance with SCHEDULE 1.

- f. When clicking the Pre/Post button, it will ask to submit a pre-trip report, where you can find carrier name, address, date, time, Truck number, VIN, Plate Number and odometer reading (it will reflect current odometer reading automatically).
- g. Trailer number which is entered manually and it is mandatory.
- h. The **accessories list** contains 22 mandatory individual items to check during post-trip. You can add additional accessories using the Nation Wide ELD website.
- i. In the **Defect Status**, you must select any one of the three radio buttons which are suitable and you have to add your comments (entering comments is mandatory) under the **Remarks Field**. Finally, the driver must **sign and save**.
- j. Once the required post-trip details have been entered and saved the data is reflected in the DVIR dashboard/page and the driver can view it on the same page.



11.2 GET LIST

Get list reflects the total number of trucks registered under a single driver name.



The DVIR report of each individual Truck number can be viewed inside the Get List by selecting the required truck number.



DVIR List

Vehicle No. :
113

Type : pre Location :
Date : 04-04-2020 Odometer : 42736.0

Delete DVIR


Are you sure you want to delete this record?

By Clicking on the Delete button, You can delete the record.



12. SIGN-OUT & SIGN-IN PAGE

Sign out/Sign in: By clicking the top left menu icon you can find an option to sign out. Once you are done with a sign out you can follow the same procedure by clicking the top left menu where you can sign in again.







13. LOG REPORT

Log Report : In the Log Report you can view 3Tabs Header, Chart and Events.

- a. Header - You can view the Current Location, Driver, Co-Driver, Vehicle, ELD and Carrier details.
- b. Chart – It displays the Hours Of Service of drivers in chart view(graphical representation).
- c. Event Logs – It displays the details of each event like Event start time, Location, Odometer, Eng Hours, Origin, Event Type/Status, and Event Comments. It will display the violation related information if the driver exceeds the duty limitations.





You can share the Log report by entering the desired email and clicking on send.

Share

Please enter email address

EMAIL

Cancel Send



14. EXCEPTION

The driver can select the following exceptions. Once he chooses and saves the exception, it will Automatically reset after 10 hours consecutive break. If any exception is enabled the driver can't choose another exception.

☰  Exception

i If you save an exception, you cannot choose another exception until consecutive 10 hour break.

- Relief from driving rules for state of emergency - 390.23
- 2 Hour driving extension for adverse driving conditions - 395.1(b)(1)
- Relief from all driving uses for emergency conditions - 395.1(b)(2)
- 30 minute break exemption for short-haul drivers(14 hour shift) - 395.1(e)(1)
- 30 Minute in-attendance break for HazMat drivers - 395.1(q) - HazMat In-attendance break
- 30 Minute Break Exemption for Oversize/ Overweight Loads - 395.3(a)(3)(ii) - Oversize/ Overweight loads

Enter reason for exception*

Save

☰  Exception

i If you had already chosen an exception, you cannot choose another exception until consecutive 10 hour break.

- Relief from driving rules for state of emergency - 390.23
- 2 Hour driving extension for adverse driving conditions - 395.1(b)(1)
- Relief from all driving uses for emergency conditions - 395.1(b)(2)
- 30 minute break exemption for short-haul drivers(14 hour shift) - 395.1(e)(1)
- 30 Minute in-attendance break for HazMat drivers - 395.1(q) - HazMat In-attendance break
- 30 Minute Break Exemption for Oversize/ Overweight Loads - 395.3(a)(3)(ii) - Oversize/ Overweight loads



15. ABOUT ELD PAGE

By clicking the top left menu About ,you can see the brief description of ELD Product, function, Application version and Latest Firmware version installed.

About

Application Version : 1.10.8
Firmware Version : Not Available
ELD Connection Status : (Not Connected)
Make : Realme
Model : RMX1827
Android Version : 9 (28)
Go to settings : [Tap Here](#)
Go to play store : [Tap Here](#)
Location Duration : 3 Seconds

About the App :

The ELD design is such that motor carriers and drivers can comply efficiently with HOS regulations and that motor carriers can make the best use of ELDs and related support systems as their primary means of recording HOS information and ensuring HOS compliance. Engine information will be shared with the ELD through integral synchronization. The ELD will be tamper-resistant so unauthorized alteration of the captured data will not occur. ELDs, certified by the providers, will meet or exceed the performance requirements. Transfer of standardized ELD data to authorized safety officials will be accomplished.

Other versions : V: 2.3.7; I: - G: 1.8; S: 2.3; P: 5.6.10
(17)



16. APP QUICK HOW - TO'S

- a. How do I ensure I am connected to the device?
 - After you have added your drivers on the Nation Wide ELD website, remove the ELD from the package and plug it into your ECM or comport. On your smartphone or tablet, download the Nation Wide ELD app and login with your Driver ID and password. Once you switch the engine on, you will be able to see the ELD hardware turning on and a blue light visible. After a few minutes the light will change to green and be stable during the entire drive time. After being on for a few minutes, your app will show details like VIN number, date, name, and ELD SSID.
- b. How do I change my duty status?
 - On the left-hand side of the app, you will see your current duty status, listed as "Driving." Click the current status to change it to "Off Duty," "On Duty Not Driving," or "Sleeper Berth." When you wish to change back, click your status again to select the appropriate status.
- c. How long can I drive before the ELD moves me into Driving status?
 - After driving for five minutes, the app will alert you that the engine is engaged and will ask if you would like to switch to Driving status, or stay in On Duty Not Driving/Off Duty/Sleeper Berth status. You have one minute to respond manually. If you have not responded after one minute and you are still driving, the app will automatically switch you into Driving status.
- d. How long can my engine idle before the ELD moves me into On Duty Not Driving status?
 - After idling for five minutes, the app will alert you that the engine is idling and will ask if you would like to switch to On Duty Not Driving Status, or stay in Driving status. You have one minute to respond manually. If you have not responded after one minute and you are still idling, the app will automatically switch you to On Duty Not Driving status.
- e. How do I record my 30-minute break?
 - On the left side of the app, you will see your current duty status, listed as "Driving" or "On Duty Not Driving." Click the current status to change it to "Off Duty." When you have completed your break, select the status "Off Duty" to change back into "Driving" or "On Duty Not Driving" status.
- f. What should I do at the end of the day?
 - At the end of the day, you will change your duty status to Off Duty or Sleeper Berth. To do so, click your current duty status, "Driving" or "On Duty Not Driving" and change it to the desired status. At the beginning of the next day, you change it back to the new status to start your day.
- g. How do I set an alarm to warn of impending violations?
 - You do not need to set an alarm. Once you or your company creates a driver profile in the back- office dashboard and selects what hourly rulesets you use to set your week, this automatically sets the app to warn you of any impending violations.
- h. How do I record when I use my truck for personal use or yard moves?
 - On the right side of the app, you will see your current driving mode, listed as "Default". Click the blue "MoD" button in the center and change your mode of driving to "Personal" or "Yard Moves." You will need to enter a comment regarding the change of mode. When you have completed your personal use or yard moves and are ready to switch back to work use, click the blue "MoD": button again and enter an appropriate comment to switch.



- i. Do Personal Moves or Yard Moves adversely affect my 34 hour off time?
 - No. Personal Moves and Yard Moves are not considered in Hours of Service.
- j. What parts of my logs can I edit?
 - You can only edit the duty status of your logs. You cannot change the length of time, location, or any other aspect of your logs.
- k. How can I edit my logs?
 - On the left side menu, select Self Inspect. Choose any log, you will get an option to edit the status. This will allow you to change the duty status of the selected log.
- l. Can the back office edit my logs for me?
 - Yes. The back officer can edit the driver logs and send the accept/deny request to the driver, Once the driver accepts the request the changes will be reflected in the driver's log.
- m. What is self-certification?
 - Self-certification is making sure that all of your logs are correct and making sure they are ready to send to the FMCSA. THIS DOES NOT SEND YOUR LOGS TO THE FMCSA.
- n. How do I complete my self-certification?
 - On the left side menu, select Certify. You will see a list of Pending logs that require certification. Select the log you wish to certify, enter any comments, check the box to certify that your entries are true and correct, and click agree. This will move the log to a list of Certified logs.
- o. Can I self-certify more than once?
 - Yes. If you see in a certified log that you have made an error and need to correct it, you can certify that log again.
- p. Can the back office certify my logs for me?
 - No. The back office cannot certify the logs.
- q. How do I complete my pre and post trip inspections?
 - On the left side menu, select DVIR. Then select the blue "Pre/Post" button. You will be asked to submit the pre-trip or post-trip report; you will see the carrier name, address, date, time, truck number, and odometer reading. You are required to manually enter the trailer number. Check the boxes of any items that need attention. In the Remarks section, select the check box for that status that fits your inspection and add your comments (this is mandatory). Finally, sign and save.
- r. How do I input my load/trip information?
 - On the left side menu, select Load Sheet. Then select the blue "+Add Load Sheets" button on the right side. You can add your load information, including date, load type, origin, destination, driver and co-driver, vehicle type, and trailer number. By clicking "Add Consignment" you will proceed to the next screen where you will add your shipper details, including shipper name, address, zip code, city, and state. You will also add consignment details including billing date, description, packing type, quantity, weight, delivery notes, and P.O. number. Finally, add the consignee details, including the consignee name, address, zip code, city, and state. The load sheet information will now be available on the main Load Sheet screen. Once you select the required load sheet, you can edit it or select it so that your load information is available on the main home dashboard so you can track your trip. When you are done with your trip, you can select the respective load sheet and remove it from the dashboard.