


EXPRESS WAY

ELD



**INSTRUCTION
MANUAL FOR
DRIVERS**

Download the mobile app to your device with a data plan.

Check on the corresponding app distribution platform if your device's operating system is compatible with the app.

DOWNLOAD THE APPLICATION

The driver's status will be displayed on the status circle and the system will calculate on-duty limits, available driving hours, required breaks, and required off-duty time. This information will be available through the app and online portal.

In order to avoid fines and penalties, alerts will be issued in the form of visual notifications and sound notifications that prevent drivers.

AUTOMATIC HOS RECORDS

After installation, duty status will be set to driving automatically when the vehicle moves at 5 mph or more.

The driver can change the duty status only when the vehicle is in full stop by tapping the status circle.

If a status is not selected after driving, the app will set it to On Duty. Personal conveyance and yard move statuses will only be available after configured through the online portal.

AUTOMATIC HOS RECORDS

DRIVE

8:31

SHIFT

10:46

CYCLE

38:18

You can access three areas of information about your current shift in the Status section:

- **Drive Time:** Shows the number of driving hours remaining in your daily shift.
- **Daily Shift:** Shows the total number of hours remaining in your shift for the day.
- **Cycle:** Shows the number of hours of driving hours remaining in your cycle.

DUTY STATUS