

# **Wireless Links**

## **DriverLog - Operation manual for Electronic Hour of Service**

Updated	20 September 2016
Revision	1.0.1

# Driver Log - HOS

## Quick Reference Guide

### Table Of Contents

#### **1 LOGIN**

- 1.1 Registering on the WIFI network.**
- 1.2 Login screen.**
- 1.3 Demo Account**
- 1.4 Licensing**

#### **2 Driver Log**

- 2.1 Main Screen**
- 2.2 Changing Your State**
  - 2.2.1 Automatic State Changes**
  - 2.2.2 Officer Screen**
  - 2.2.3 Inspection State**
- 2.3 Entry View**
- 2.4 Extended View**
- 2.5 Getting To Other Screens**
- 2.6 Violations**
- 2.7 Submit Button – ELECTRONIC SIGNATURE**
- 2.8 Program Bugs or Errors**
- 2.9 Info Button**
- 2.10 External Devices/BlueLink**

#### **3 Cycle Report**

- 3.1 Cycle Reset**

#### **4 Calendar**

#### **5 Edit**

- 5.1 Easy Edit**
- 5.2 Edit Existing event**
- 5.3 Add entry before/after event**
- 5.4 Delete entry**

#### **6 About**

- 6.1 Sending Logs**

#### **7 WIFI**


# 1 LOGIN

## 1.1 Registering on the WIFI network.

The Piccolo Plus acts as a WIFI Hot Spot, and can provide an internet connection to your Android Tablet. This is not needed if you are using a phone, since the phone has its own data plan.

To connect to the WIFI Hot Spot, you need to first log into the WIFI network. The network name for your Piccolo provided WIFI is typically “WLI” plus your truck # (eg WLI1234). The password to the WIFI is available from your Dispatcher. Further explanations on how to set up your WIFI can be found in the WIFI section #7 at the end of this manual.

Click “I Agree” to begin using the app. Clicking ‘Cancel’ will exit the app.



## 1.2 Login screen.

- **Driver ID** - essentially your username.
- **PIN** - your password. Default **PIN** is **2014**. You can change your **PIN** after you log in.
- **Manifest** - the number assigned to the cargo you are transporting.
- **Odometer** - should be automatically filled from your truck engine sent via the Piccolo Plus GPS unit, if it's not then fill it in manually.
- **City/State** - should be filled in automatically by the tablet GPS. If it is not, you will have to fill it in manually.
- **Tractor** - the name given to the truck you are driving.
- **Drive** - a dropdown menu where you can switch between Long Haul and Short Haul as directed by your supervisor
- **Trailer 1 and Trailer 2** - the trailers name /numbers and to be filled only if you have a trailer hooked up.
- **Co Driver** - should be filled out when you have a co-driver in the truck with you.

### Legend

- **Not a required field**
- **Required field**

Wireless Links Inc.  
11/17/2015 12:11 PM EST

Your username	➔	Driver ID	mark	PIN	2014	➔	Initially set to 2014
Transport Document Number	➔	Manifest	Manifest	Odometer	0	➔	Odometer entered from JBUS via Piccolo
Location entered by GPS	➔	City	Lyndhurst	State	New Jersey	➔	Location entered by GPS
Your truck's username	➔	Tractor	3050	Drive	Long Haul	➔	Long Haul/Short Haul dropdown
Trailer Number, if applicable	➔	Trailer 1	Trailer 1	Trailer 2	Trailer 2	➔	Trailer Number, if applicable
Your Co Driver's name	➔	Co Driver	Co Driver				

Login button

Legend

- ➔ Required
- ➔ Not Required

For training, just enter **demo** in the **DRIVER ID** field and press log in.

### 1.3 Demo Account

For your convenience, we have provided a demo account with Driver Log version 10.8 and up. This is for training purposes, and getting familiar with the application.

For the demo account, you need only put “Demo” in the Driver ID field, and nothing else is required. Simply click Log In, afterwards, and you will have access to a demo account with seven days of data in the logs. It is fully possible to interact with the demo account, this is so you can practice the different features and get a feel for and familiarity with the environment.

Wireless Links  
11/6/2015 04:08 PM EST

Driver ID Demo ← Type Demo PIN PIN

Manifest Manifest Odometer Odometer

City Lyndhurst State New Jersey ← Note: City/State may be auto-filled in. If they are, you can leave them alone. If they are not, you can leave them blank.

Tractor Tractor Drive Long Haul

Trailer 1 Trailer 1 Trailer 2 Trailer 2

Co Driver Co Driver


Login ← Then, click here.

## 1.4 Licensing

Once you have completed the LOGIN screen and clicked "Login", you must fill in the authorization form below. You only need to do this the first time you log in.

The Group ID is the username for your company and should be provided to you by your Fleet Manager or Dispatcher. If you are a Fleet Manager, and are unsure of your Group ID, please call Wireless Links.

Click Group ID and fill in your Group ID with the pop up keyboard that should appear. Click "Check License" when you have entered your Group ID.



## 2 Driver Log

This is your main screen, from this screen you will be accessing different function of the Driver Log application.

### 2.1 Main Screen

- You can change your status (eg **DRIVING, ON DUTY NOT DRIVING, ADVERSE DRIVING**, etc) from this screen
- You can see the history of your status changes
- You can see your cycle/shift balance and on-duty time
- You can get to all of the other screens from this screen

**NOTE: Officer with a Green face means no diagnostic errors, Orange means at least one diagnostic error, and Red means at least one malfunction.**

If you connect a Bluelink or Piccolo STX-B instead of a Piccolo Plus WIFI, you would see BL in the place of PiC.

## 2.2 Changing Your State

Many of these statuses should be self-explanatory, such as **OFF DUTY**, **DRIVING**, **ON DUTY – NOT DRIVING**, and **LOGOUT**. The rest are as follows:

- **SLEEPER BERTH** – if you are not using a day cab, and are going off duty to sleep in the bed in the truck, select this button.
- **ADVERSE DRIVING** – if you are in “snow, sleet, fog, other adverse weather conditions, a highway covered with snow or ice, or unusual road and traffic conditions” that are out of your control and keeping you from sticking to your schedule, click this button
- **COMMENT** – any notable entries that you want to record where another button does not apply, click this button and write in your note
- **NEW MANIFEST** – this button allows you to switch to a new manifest during the shift you are in.
- **SWITCH TRUCK** – relevant only if you are switching trucks during your shift.
- **ON DUTY – NOT DRIVING** – There are multiple “On Duty job” reasons to select from for this status. These include “Yard Work”, “Fueling”, “Loading” and “Unloading”, as well as “Pre-Trip Inspection” and “Post-Trip Inspection”
  - **“Pre-Trip” and “Post-Trip Inspection”** – If you have the external application DVIR installed and set up (please see DVIR manual for set up), clicking on either of these Inspection reasons will launch the application, allowing you to fill out a Driver Vehicle Inspection Report from your handheld device. Please see section 2.2.3 for more detail.
  - **“Inspection”** – If you select a different ON DUTY state, but still need to do an Inspection of your vehicle, the Big Green Button will now have an “Inspection” status to select from where you can choose “Pre-Trip” or “Post-Trip”. Please see section 2.2.4 for more detail.




## 2.2.1 Automatic State Changes

The Driver Log application can automatically change your state to DRIVING or to ON DUTY – NOT DRIVING.

- A. For compliance, the tablet will change you to a DRIVING state if you are driving above five miles per hour.
- B. You are prompted to switch to ON DUTY – NOT DRIVING after five minutes if you are not moving. If you do not click on the prompt, it will change your state after one additional minute.

**NOTE: Changing Status to OFF DUTY must be done by the driver.**



## 2.2.2 Officer Screen

Selecting the Police View button, you can present your logs for officer inspection. They will see the screen below, where the can optionally send your report to the appropriate place.

**Wireless Links Inc.**  
6/29/2016 09:06 AM EDT

**Police View**

Record Date	USDOT #	Driver license Number	Driver License State	ELD ID	Trailer ID
6/26/2016 05:50 AM EDT	Unknown	ABCD1234FG	NJ	ELD ID XXX	

Time Zone	Driver Name	Co-Driver Name	ELD Manufacturer	Shipping ID	Data Diagnostics Indicators
	Unknown		Wireless Links Inc.		No

24 Period Starting Time	Driver ID	Co-Driver ID	Trunc Tractor ID	Unidentifier Driver Record	ELD Malfunction Indicator
Midnight	demo			No	No

Carrier	Start End Odometer	Miles Today	Trunc Tractor VIN	Exempt Driver Status	Start End Engine Hours
Wireless Links Inc.	1405-1405	0		No	1343240-1343240

Current Location	File Comment	Print/Display Date
New York, NY		29-Jun-16

Time	Location	Odometer	Eng Hours	Event type / Status	Origin
25-Jun-16					
00:50	New York, NY	1405.0	0	Off Duty	Driver
26-Jun-16					
12:50	New York, NY	1405.0	0	Login	Driver
13:00	New York, NY	1405.0	0	On Duty	Driver
15:30	New York, NY	1405.0	0	Driving	Driver
21:30	New York, NY	1405.0	0	On Duty	Driver
22:00	New York, NY	1405.0	0	Off Duty	Driver
01:21	New York, NY	1405.0	0	Logout	Driver

Timeline Graph Data:

Event	Time	Odometer	Eng Hours
OFF	6:00		
ON	2:30		
OFF	6:00		
ON	8:59		
OFF	03:00		
ON	06:00		
OFF	14:59		
ON	23:59		

Buttons: Add comment, Send report, 3 days ago

## Pre-Trip and Post-Trip Inspections

If you have the external application DVIR installed and set up (please see DVIR manual for set up), clicking on either of these On Duty job reasons will launch the application, allowing you to fill out a Driver Vehicle Inspection Report from your handheld device. With the form filled out as below, click "OK" to be brought to the DVIR screen.

The screenshot displays the Driver Log application interface. At the top, it shows 'Wireless Links' and 'Driver Log' with a date and time of 9/19/2016 03:46 PM EDT. The driver name is listed as 'null null'. A summary table shows the following data:

	ON DUTY TILL NOW	DRIVING BALANCE
CYCLE	55:43	14:16
SHIFT	08:54	03:46

The background interface includes a speedometer showing 88.0 MPH, a fuel gauge at 50%, and a 'Miles Today' indicator. A timeline at the bottom shows duty status: OFF DUTY (6:00), SLEEPER BERTH (00:00), DRIVING (5:31), and ON DUTY (NOT DRIVING) (1:38). A summary table on the right shows 'TOTAL HOURS' for each status: OFF DUTY (06:51), SLEEPER BERTH (00:00), DRIVING (07:13), and ON DUTY (01:39).

The foreground dialog box is titled 'Starting On Duty - not driving State' and contains the following information:

- On Duty job: Post-Trip Inspection
- Start Time: 12:42 PM
- Odometer: 604
- Location: Boston, MA

The dialog box has 'Cancel' and 'OK' buttons at the bottom.

Below is the DVIR application. If it is set up correctly, you should see the Company Name and Address filled out. Other fields should fill in as well based on your Driver Log settings. Please note that the “Pre trip” option is automatically selected because I chose a “Pre Trip” “On Duty job” reason. Please verify the information before clicking “Next”.


The screenshot shows a mobile application interface for a Driver Vehicle Inspection Report (DVIR). The title bar at the top is black with a white back arrow and the text "WLI DVIR". The status bar above it shows various icons and the time "5:00 PM" with a 71% battery level. The main content area is white and contains the following text and form fields:

Pre trip - DRIVER'S VEHICLE INSPECTION REPORT  
As required by the Federal Motor Carrier Safety Regulations for Commercial Drivers


Date	06/01/2016 4:58 PM
Company Name	Example Inc
Company Address	1050 Wall St NY, NY
Driver ID	John
Driver Name	John Faulkner
Truck/Tractor No.	748
Trailer No.	871
Odometer	36589

Below the form fields are two radio buttons: "Pre trip" (which is selected) and "Post trip". At the bottom of the form are two buttons: "CANCEL" and "NEXT".

On the following screen, please add remarks for any noteworthy defects by checking the boxes and filling out the field that pops up, as below. Click “Save” to confirm each remark. And click “Next” to continue. There are two screens with checkboxes, so please review both if you are having trouble finding your specific defect category.




On the last screen, you and your mechanic can sign off on the DVIR. Clicking the open field pops up a fill-in signature pad where you can sign your name. Complete the report by selecting “Save & Send”



## 2.2.3 Inspection State


If you entered an “ON DUTY – not driving” state other than Pre-Trip or Post-Trip Inspection (eg Yardwork), and still need to enter an Inspection into DVIR, then you will find a new option listed when you click the Big Green Button, “Inspection”.



Clicking “Inspection” will give you the screen below, where you can choose a “Pre trip” or a “Post trip” inspection state. Both options will launch DVIR.

## 2.3 Entry View

In order to view more entries at once you can expand the view screen by holding and dragging up on the chart, to see this view of the main page. Each of these status changes can be clicked on for a more detailed view. See the next page for an example of this.






## 2.4 Extended View

Tapping a status change shows additional information about the change. The chart has a little red arrow which shows where the status change occurred. The additional information includes details such as entry creation date, location, and any other fields added by the driver at the time of the change.

With your finger on the chart, you can drag down to return to the main view of the screen.



## 2.5 Getting To Other Screens

Clicking on **Driver Log** at the top center of the screen you can select from several other screens and see

- **Cycle Report**
- **Calendar**
- Toggle on and off **Deleted Entries**
- And the **About** section


There is also the option to change your **PIN** from this dropdown. Please be careful and only change your **PIN** if you are sure you can remember the new **PIN**.

Each of these screens are explained further below.

## 2.6 Violations

You will see red lines in the graph when you were in **VIOLATION**. You can click on **VIOLATION** in the log list below the graph to see details about the violation.

**NOTE:** As you can see in the picture below, **VIOLATIONS** are also visible from the **Cycle Report**.



## **2.7 Submit Button – ELECTRONIC SIGNATURE**

At the end of every shift, make sure you submit your log. Clicking the submit button acts as an electronic signature, verifying the accuracy of your logs. This is just like signing your current paper logs.

Confirm your submission on the screen that follows.

## **2.8 Program Bugs or Errors**


It is important to submit a log every time your Driver Log application has a problem. See Section 6 on sending logs for instructions on how to do this.

You can help further by taking a screenshot to include with your log. Taking screenshots can change from device to device, but with most Samsung devices, you can take a screenshot by holding on the power button and home button of the tablet at the same time for five seconds (until the screen flashes). The power button can be found on the top of the right side of the tablet, and the home button is the big button on the front. Submitting the screenshot will be explained further in Section 6.


## 2.9 Info Button

The info button in the dropdown under “Driver Log” (see bottom left screenshot) opens the screen shown in the bottom right screenshot. This is a snapshot of your daily general info. Click on **JBUS DATA** to see information about your current location and engine information (loaded from a BlueLink or Piccolo device).

**NOTE: In some trucks, especially older models, there is a discrepancy between the odometer from the JBUS, that is your truck’s computer, and the odometer on your truck’s dashboard. The Driver Log odometer entry is based on the automatic entry from the odometer field on the JBUS. In the case that an officer is questioning the validity of the distance you have travelled, by pressing on current JBUS Data, the tablet will display the current odometer reading from the JBUS and the GPS Location and RPM. This will show you the discrepancy mentioned here.**



## 2.10 External Devices/BlueLink



1. When in settings go to "External Devices"
  - a. If you have a Piccolo Plus with WIFI select "Attach to Piccolo"
  - b. If you use a BlueLink dongle or a Piccolo STX with Bluetooth select "Attach to BlueLink unit"
2. If you selected BlueLink then you have the option to limit the communication:
  - a. between your device to any BlueLink or to a specific BlueLink if you select "Limit BlueLink Connection" ON, and then click on BlueLink ID and enter the specific BlueLink ID of a specific truck (this is the equivalent of selecting SSID when using WIFI)
  - b. If the "Limit BlueLink Connection" is not ON then DriverLog will link with the first BlueLink is connecting to, so if there are a few trucks one next to the other it could link with any truck.




## 3.1 Cycle Reset

You can reset your cycle if and only if you have been off duty for 34 hours. This cycle reset is named, the 34-hour Off Duty Cycle Reset. Driver log keeps track of this for you and if you have been OFF DUTY for 34 hours, it will show you the following pop up to reset your cycle.

If you don't see this pop up, you can also click the "Tap to Reset Cycle" button to produce the pop up

# Calendar

The calendar screen is where you can see a history log of all status changes.





By clicking on “Select Date”, you can select a time you wish to toggle in the history log view. Simply click the day you want to display on the **Calendar**.


# Edit

Driver Log version 12.8 and newer use the easy edit described below. If you are using an older Driver Log, please ask for an older manual. Thanks.

## 5.1 Easy Edit

The easy edit is an “inline” edit. This means edits take place in the line where they are meant to go. So, if you need to add an event to some time at the end of yesterday, such as, right before your OFF DUTY event, you would go to that OFF DUTY event, press and hold there, and select from a pop-up screen: Add event before OFF DUTY. A new pop up would appear with your event choices and you can select the appropriate event.

As you can see in the screenshot, there is also the option to edit the already existing event, or to add an event before/after, or delete the already existing event. Simply select the option appropriate to your case and choose the corresponding action.



## 5.2 Edit Existing event


If you need to change an already existing event, find the event in your calendar, press and hold the event, and click “Edit [EVENT NAME]”. This will present you with a dialog box much like when you are creating a new event.

In the example below, I am editing my Off Duty entry to five minutes earlier. I did this by tapping the “Change” button next to time and selecting my new date and time. After completing my changes, I would click “OK” and the new changed time would appear.

## Add entry before/after event

If you need to add an entry before or after an already existing event, press-and-hold on the already existing event and select “Add event [before/after] [EVENT NAME]”.


For this example, I will add a Post-Trip Inspection entry before my OFF DUTY. So, after clicking “Add event before OFF DUTY”, I will see the screen below, where I will click “ON DUTY – not driving”



Next I select the “On Duty job” and change the start time, set the odometer, city, state, and fill in the addition info as seen below. All of this should be exactly the same as if you were creating the event in the correct order the first time around. The only difference is that you have to set the start time. When you are done, you can click “OK” and you should see your new entry in the list. If you are adding an event to a previous day, you may have to go to the Calendar screen and select that day to see the new entry.

## 5.3 Delete entry

If you need to delete an entry, press and hold on the entry, and click “Delete”. A confirmation screen may appear, like below. Tap “Confirm Delete” to complete the deletion of the entry. If you are having trouble finding the entry you want to delete, please go to the Calendar screen and choose the day where the entry should have occurred.




## 6 About

This screen tells you the version number of the app, and gives you the ability to send logs.

### 6.1 Sending Logs

Click “**Send Problem Report**” to send logs.




On the screen below, please fill out the Problem Description and a brief explanation of How the issue occurred. Then click "Submit".




# 7 WIFI

If you are having trouble connecting to the **WIFI**, you are in the right place.

**Drag down** from the very top of the tablet, near the middle. **You may need to do this twice** in a row to get the menu shown below. Next, **press and hold your finger** on “**Wi-Fi**” for **3 to 5 seconds**.




Make sure **Wi-Fi** has a green bar next to it, like below in the **Network Connections** pane on the left of the screen. **If it doesn't, slide the bar to make it green.** Next, **tap your WI-FI Network name** (mine is R7KBD) your **Piccolo WI-FI name** will likely be **WLI** with a string of numbers (**Your Truck #**) after it (eg **WLI05142**).




Now **type** in the **password** to the **WI-FI** on your tablet **using** the **pop up keyboard** that should appear on the screen. If you don't have the password, ask your Fleet Manager or Dispatcher. Now **click** "**Connect**".


You can return to the app you were using before by **clicking the home button** on your tablet and navigating to and **clicking on the app icon**.




If you don't get prompted for a password, but get a page like the one below, then you are already connected to the **WIFI**.



If you get a page like the one below, when you **click** on your **WIFI Network name**, then the password has already been entered, but the **WIFI is not in range** (that is, the signal is too far away, or not on at all).



To ensure that you always reconnect to the WiFi when you come in range, please click the tile icon indicated in the screenshot below and select “Advanced”



The screenshot shows a mobile settings application with a dark blue header. The header has four tabs: "Connecti..", "Device", "Controls", and "General". Below the header, there are several icons: "Scan", "Wi-Fi Direct", a magnifying glass, and a vertical ellipsis (three dots) icon. A red box highlights the vertical ellipsis icon, and a red arrow points to it with the text "Click here".

Below the header, the settings are organized into sections. The "NETWORK CONN..." section includes:

- Wi-Fi: On (green slider)
- Bluetooth: On (green slider)
- Airplane m..: Off (grey slider)
- Data usage: On (orange icon)
- Location: On (green slider)
- More netwo..: On (blue icon)

The "CONNECT AND S..." section includes:

- Nearby dev..: Off (grey slider)

The "Wi-Fi" section is expanded, showing a list of networks:

- 6T35F: Not in range
- FIOS-LEPVF: Not in range
- Office: Not in range
- R7KBD: Not in range
- WLI04: Not in range
- WLI3050: Not in range
- WLI827843: Not in range
- WLIcd826777: Not in range
- WLIcd826778: Not in range
- WLIorion: Not in range

At the bottom of the Wi-Fi section, there is a green plus sign and the text "Add Wi-Fi network".

On the right side of the Wi-Fi section, there is a menu with the following options:

- Advanced
- WPS push button
- WPS PIN entry
- Help

As indicated on the screen below, click Wi-Fi Timer

The screenshot shows the Windows Settings application with the 'Connectors' tab selected. The left sidebar lists various network-related settings, including Wi-Fi, Bluetooth, Airplane mode, Data usage, Location, and More network options. The main pane displays the 'Wi-Fi > Advanced' settings. The 'Wi-Fi timer' option is highlighted with a red box, and a red arrow points to it with the text 'Click here'. Other settings shown include 'Network notification' (checked), 'Sort by' (Signal strength), 'Keep Wi-Fi on during sleep' (Always), 'Always allow scanning' (checked), 'Install certificates', 'MAC address' (8C:BF:A6:99:01:6D), and 'IP address' (fe80::8ebf:a6ff:fe99:16d, 192.168.1.214).

Connector | Device | Controls | General

NETWORK CONN...

Wi-Fi

Bluetooth

Airplane m..

Data usage

Location

More netwo..

CONNECT AND S...

Nearby dev..

Wi-Fi > Advanced

Network notification   
Receive notifications when open networks in range are detected.

Sort by  
Signal strength

Keep Wi-Fi on during sleep  
Always

Always allow scanning   
Let Google Location Service and other applications scan for Wi-Fi networks, even when Wi-Fi is off.

**Wi-Fi timer**  
Automatically connect to or disconnect from Wi-Fi networks. **Click here**

Install certificates

MAC address  
8C:BF:A6:99:01:6D

IP address  
fe80::8ebf:a6ff:fe99:16d  
192.168.1.214

Now click the check boxes for “SET START TIME” and “SET END TIME” and then adjust the values to 12:00 AM for the start time and 11:59 PM for the end time. Then click “Done”. You should now automatically reconnect to WiFi when in range.

