



Prometheus - HOS

DriverLog - Operation manual For Electronic Hour of Service

Updated	12 February 2017
Revision	1.0.1

THIS DOCUMENT CONSTITUTE HIGHLY SENSITIVE AND PROPRIETARY TRADE SECRETS AND CONFIDENTIAL INFORMATION ABOUT WIRELESS LINKS PROPRIETARY COMMUNICATION TECHNOLOGY. INTEGRATOR MUST STRICTLY OBSERVE ALL RESTRICTIONS IMPOSED BY PROMETHEUS IN THE EXECUTED NDA AND/OR LICENSE AGREEMENT.

Driver Log - HOS

Quick Reference Guide

Table of Contents

1 LOGIN

- 1.1 Registering on the WIFI network.
- 1.2 Login screen.
- 1.3 Demo Account
- 1.4 Licensing

2 Driver Log

- 2.1 Main Screen
- 2.2 Changing Your State
 - 2.2.1 Automatic State Changes
 - 2.2.2 Officer Screen
 - 2.2.3 Pre-Trip and Post-Trip Inspections
 - 2.2.4 Inspection State
- 2.3 Entry View
- 2.4 Extended View
- 2.5 Getting To Other Screens
- 2.6 Violations
- 2.7 Submit Button – ELECTRONIC SIGNATURE
- 2.8 Program Bugs or Errors
- 2.9 External Devices/BlueLink
- 2.10 Canada HOS

3 Cycle Report

- 3.1 Cycle Reset

4 Calendar

5 Edit

- 5.1 Easy Edit
- 5.2 Edit Existing event
- 5.3 Add entry before/after event
- 5.4 Delete entry

6 Info Button

7 About

7.1 Sending Logs

7 WIFI

1 LOGIN

1.1 Registering on the WIFI network.

The Starlink 4G/Wifi acts as a WIFI Hot Spot, and can provide an internet connection to your Android Tablet. This is not needed if you are using a phone, since the phone has its own data plan.

To connect to the WIFI Hot Spot, you need to first log into the WIFI network. The network name for your Starlink provided WIFI is typically “Starlink” plus your truck # (eg TR1234). The password to the WIFI is available from your Dispatcher. Further explanations on how to set up your WIFI can be found in the WIFI section #7 at the end of this manual.

1.2 Login screen.

- **Driver ID** - essentially your username.
- **PIN** - your password. Default **PIN** is **2014**. You can change your **PIN** after you log in.
- **Manifest** - the number assigned to the cargo you are transporting.
- **Odometer** - should be automatically filled from your truck engine sent via the Bluelink unit, if it's not then fill it in manually.
- **City/State** - should be filled in automatically by the tablet GPS. If it is not, you will have to fill it in manually.
- **Tractor** - the name given to the truck you are driving.
- **Drive** - a dropdown menu where you can switch between Long Haul and Short Haul as directed by your supervisor
- **Trailer 1 and Trailer 2** - the trailers name /numbers and to be filled only if you have a trailer hooked up.
- **Co Driver** - should be filled out when you have a co-driver in the truck with you.

The screenshot shows the login screen for Turnkey Trading LLC. The screen is dark-themed with white text. At the top, it displays the company name and the date/time: 2/12/2017 12:23 PM EST. The login form consists of several fields with labels and values:

Driver ID	Carlos	PIN	****
Manifest	Manifest	Odometer	Odometer
City	Miami	State	Florida
Tractor	10	Drive	Long Haul
Trailer 1	11	Trailer 2	Trailer 2
Co Driver	Co Driver	Co Driver ID	Co Driver ID

Red arrows point to the following fields and values:

- Your Username: Driver ID Carlos
- Transport Document #: Manifest Manifest
- Location Entered by GPS: City Miami, State Florida
- Truck #: Tractor 10
- Trailer # If Applicable: Trailer 1 11, Trailer 2 Trailer 2
- Co Driver Name: Co Driver Co Driver
- Initially Set to 2014: PIN ****
- Odometer Entered from JBUS: Odometer Odometer
- Location Entered by GPS: State Florida
- Long/Short Haul Dropdown: Drive Long Haul
- Trailer # If Applicable: Trailer 2 Trailer 2
- Login Button: Login

1.3 Demo Account

For your convenience, we have provided a demo account with Driver Log version 10.8 and up. This is for training purposes, and getting familiar with the application.

For the demo account, you need only put “Demo” in the Driver ID field, and nothing else is required. Simply click Log In, afterwards, and you will have access to a demo account with seven days of data in the logs. It is fully possible to interact with the demo account, this is so you can practice the different features and get a feel for and familiarity with the environment.

1.4 Licensing

Once you have completed the LOGIN screen and clicked "Login", you must fill in the authorization form below. You only need to do this the first time you log in.

The Group ID is the username for your company and should be provided to you by your Fleet Manager or Dispatcher. If you are a Fleet Manager, and are unsure of your Group ID, please call FlexGPS.

Click Group ID and fill in your Group ID with the pop up keyboard that should appear. Click "Check License" when you have entered your Group ID.

2 Driver Log

This is your main screen, from this screen you will be accessing different function of the Driver Log application.

2.1 Main Screen

- You can change your status (eg **DRIVING**, **ON DUTY NOT DRIVING**, **ADVERSE DRIVING**, etc) from this screen
- You can see the history of your status changes
- You can see your cycle/shift balance and on-duty time
- You can get to all of the other screens from this screen

The screenshot shows the main interface of the Driver Log application. At the top, it displays the company name 'Turnkey Trading LLC' and the date '2/12/2017 12:40 PM EST'. The driver's name 'Carlos Landrian' is shown next to a US flag icon. A table displays cycle and shift balances for 'ON DUTY' and 'DRIVING' status. A large green button indicates the current status is 'ON DUTY NOT DRIVING'. A speedometer shows '0 MPH' and 'BL' for BlueLink. A graph at the bottom shows driving status over a 24-hour period. Callouts with red arrows point to various features: 'Officer Inspection Screen', 'US Flag = US Rules / CA Flag = Canadian Rules', 'Cycle Balance', 'Shift Balance', 'Big Green Button is Current Status Press to Change Status', 'Graph of Driving Status for the Day', 'Pull Up Graph to See Detailed List of All your Entries for the Day', 'Bluelink: Red Disconnected / Green Connected', 'Current Speed', and 'Distance Driven Today'.

	ON DUTY TILL NOW	DRIVING BALANCE
CYCLE	98:55	-28:55
SHIFT	98:55	-84:56

	OFF DUTY	SLEEPER BERTH	DRIVING	ON DUTY (NOT DRIVING)	TOTAL HOURS
	0:00	0:00	0:00	12:40	12:40

NOTE: Officer with a Green face means no diagnostic errors, Orange means at least one diagnostic error, and Red means at least one malfunction.

If you connect a Bluelink you would see BL in the place of PiC



2.2 Changing Your State

Many of these statuses should be self-explanatory, such as **OFF DUTY**, **DRIVING**, **ON DUTY – NOT DRIVING**, and **LOGOUT**. The rest are as follows:

- **SLEEPER BERTH** – if you are not using a day cab, and are going off duty to sleep in the bed in the truck, select this button.
- **ADVERSE DRIVING** – if you are in “snow, sleet, fog, other adverse weather conditions, a highway covered with snow or ice, or unusual road and traffic conditions” that are out of your control and keeping you from sticking to your schedule, click this button
- **COMMENT** – any notable entries that you want to record where another button does not apply, click this button and write in your note
- **NEW MANIFEST** – this button allows you to switch to a new manifest during the shift you are in.
- **SWITCH TRUCK** – relevant only if you are switching trucks during your shift.
- **ON DUTY – NOT DRIVING** – There are multiple “On Duty job” reasons to select from for this status. These include “Yard Work”, “Fueling”, “Loading” and “Unloading”, as well as “Pre-Trip Inspection” and “Post-Trip Inspection”
 - **“Pre-Trip” and “Post-Trip Inspection”** – If you have the external application DVIR installed and set up (please see DVIR manual for set up), clicking on either of these Inspection reasons will launch the application, allowing you to fill out a Driver Vehicle Inspection Report from your handheld device. Please see section 2.2.3 for more detail.
 - **“Inspection”** – If you select a different ON DUTY state, but still need to do an Inspection of your vehicle, the Big Green Button will now have an “Inspection” status to select from where you can choose “Pre-Trip” or “Post-Trip”. Please see section 2.2.4 for more detail.
- **Yard Moves** – A special ON DUTY state for yard work where the vehicle is driving, but only around the yard. This state will keep you in an ON DUTY state rather than automatically switch you to a DRIVING state when motion is detected.

See the next page for example images.

Clicking on the big green button, you can see all of the statuses. If you cannot see all of them, scroll to see the rest.

The screenshot shows the Driver Log application interface for Turnkey Trading LLC on 2/12/2017 at 12:40 PM EST. The driver is Carlos Landrian. The interface includes a summary of the current cycle and shift, a speedometer, a status indicator, a duty cycle chart, and a list of status options.

Summary:
 Shift used: 98:56
 Cycle On Duty: 98:55, Over: 28:55
 Negative driving balance: 84:56
 Driver name: Carlos Landrian

	ON DUTY TILL NOW	DRIVING BALANCE
CYCLE	98:55	-28:55
SHIFT	98:55	-84:56

Speedometer: 000 MPH, BL Miles Today

Status Indicator: ON DUTY NOT DRIVING

Duty Cycle Chart: A grid showing duty cycle from MID-NIGHT to 11 NOC. The current status is ON, starting at 12:27.

Status Options:

- OFF DUTY
- SLEEPER BERTH
- DRIVING
- INSPECTION
- ADVERSE DRIVING
- AUTHORIZED PERSONAL USE
- YARD MOVES
- COMMENT
- NEW MANIFEST


Additional Information:
 2/12/2017 12:25 PM EST
 2/12/2017 12:24 PM EST
 2/12/2017 12:23 PM EST
 2/12/2017 12:21 PM EST
 2/12/2017 12:20 PM EST
 Seq Num: 39, Status: Active, Origin: Driv
 Odometer: 42000
 Location: Miami, Florida
 Longitude: -80.4149825, Latitude: 25.68
 Tractor:10, Trailer:11, Drive:Long Haul,
 Serial:5b861a39-rotohos.wlius.com, Ver

2.2.1 Automatic State Changes

The Driver Log application can automatically change your state to DRIVING or to ON DUTY – NOT DRIVING.

- A. For compliance, the tablet will change you to a DRIVING state if you are driving above five miles per hour.
- B. You are prompted to switch to ON DUTY – NOT DRIVING after five minutes if you are not moving. If you do not click on the prompt, it will change your state after one additional minute.

NOTE: Changing Status to OFF DUTY must be done by the driver.



2.2.2 Officer Screen



Selecting the Police View button (see left), you can present your logs for officer inspection. They will see the screen below, and using the buttons at the bottom of the screen, they can send your report to any email (to the officer themselves or to the DOT) with any comments they want. The email will be in the format requested by the DOT final ruling.

Turnkey Trading LLC
2/12/2017 12:41 PM EST

Officer View

Record Date	USDOT #	Driver license Number	Driver License State	ELD ID	Trailer ID
2/12/2017 12:19 PM EST	Unknown	123456	Unknown	ELD ID XXX	11
Time Zone	Driver Name	Co-Driver Name	ELD Manufacturer	Shipping ID	Data Diagnostics Indicators
EST	Carlos F Landrian		Wireless Links Inc.		Yes
24 Period Starting Time	Driver ID	Co-Driver ID	Trunc Tractor ID	Unidentifier Driver Record	ELD Malfunction Indicator
Midnight	Carlos		10	No	No
Carrier	Start End Odometer	Miles Today	Trunc Tractor VIN	Exempt Driver Status	Start End Engine Hours
Turnkey Trading LLC	42000-42000	0		No	0-0
Current Location	File Comment			Print/Display Date	
Miami, FL				12-Feb-17	

MID-NIGHT	1	2	3	4	5	6	7	8	9	10	11	NOON	1	2	3	4	5	6	7	8	9	10	11	TOTAL HOURS
OF																								00:00
SL																								00:00
DR																								00:00
ON																								12:41

Time	Location	Odometer	Eng Hours	Event type / Status	Origin
08-Feb-17					
09:43	Orlando, FL	40850.0	0	On Duty	Driver
12-Feb-17					
11:18	Miami, Florida	42000.0	0	Logout	Driver
12:19	Miami, FL	42000.0	0	Login	Driver
12:20	Miami, FL	42000.0	0	Logout	Driver
12:20	Miami, Florida	42000.0	0	Login	Driver
12:21	Miami, Florida	42000.0	0	Logout	Driver
12:23	Miami, Florida	42000.0	0	Login	Driver
12:24	Miami, Florida	42000.0	0	Logout	Driver
12:25	Miami, Florida	42000.0	0	Login	Driver
12:25	Miami, Florida	0.0	0	Data Diagnostic - 3	Auto
12:27	Miami, Florida	42000.0	0	Off Duty	Driver
12:27	Miami, Florida	42000.0	0	On Duty	Driver

Add comment Send report Today

2.2.3 Pre-Trip and Post-Trip Inspections

If you have the external application DVIR installed and set up (please see DVIR manual for set up), clicking on either of these On Duty job reasons will launch the application, allowing you to fill out a Driver Vehicle Inspection Report from your handheld device. With the form filled out as below, click “OK” to be brought to the DVIR screen.

Turnkey Trading LLC
2/12/2017 12:27 PM EST
Driver Log

OFF Duty / Sleeper Berth for 00:00
Shift reset at 2/12/17 10:27 PM
Cycle reset at 2/13/17 10:27 PM

Driver name - Carlos Landrian

	ON DUTY TILL NOW	DRIVING BALANCE
CYCLE	98:43	-28:43
SHIFT	98:43	-84:43

Starting On Duty State

On Duty job Pre-Trip Inspection

Start Time: 12:27 PM Change

Odometer 42000 Miami Florida

Additional info

Cancel OK

Miles Today

MID-NIGHT 1

	TOTAL HOURS
OFF DUTY	00:00
SLEEPER BERTH	00:00
DRIVING	00:00
ON DUTY (NOT DRIVING)	12:27

MID-NIGHT 1 2 3 4 5 6 7 8 9 10 11 NOON 1 2 3 4 5 6 7 8 9 10 11

2/12/2017 12:27 PM EST OFF DUTY

2/12/2017 12:25 PM EST DATA DIAG LOGGED

Below is the DVIR application. If it is set up correctly, you should see the Company Name and Address filled out. Other fields should fill in as well based on your Driver Log settings. Please note that the “Pre trip” option is automatically selected because I chose a “Pre Trip” “On Duty job” reason. Please verify the information before clicking “Next”.

← WLI DVIR

PRE TRIP - DRIVER'S VEHICLE INSPECTION REPORT
As required by the Federal Motor Carrier Safety Regulations for Commercial Drivers

Date	12/02/2017 12:27 PM
Company Name	Turnkey Trading LLC
Company Address	12973 SW 112 Street Suite 239 Miami, FL 33186
Driver ID	Carlos
Driver Name	Carlos F Landrian
Truck/Tractor No.	10
Trailer No.	11
Odometer	

Pre trip Post trip

CANCEL NEXT

On the following screen, please add remarks for any noteworthy defects by checking the boxes and filling out the field that pops up, as below. Click "Save" to confirm each remark. And click "Next" to continue. There are two screens with checkboxes, so please review both if you are having trouble finding your specific defect category.

← WLI DVIR

PRE TRIP - DRIVER'S VEHICLE INSPECTION REPORT
As required by the Federal Motor Carrier Safety Regulations for Commercial Drivers

<input type="checkbox"/> Air Compressor	<input type="checkbox"/> Heater	<input type="checkbox"/> Safety Eq. - Flags-Flares-Fusees
<input type="checkbox"/> Air Lines	<input type="checkbox"/> Horn	<input type="checkbox"/> Safety Eq. - Spare Bulbs & Fuses
<input type="checkbox"/> Battery	<input type="checkbox"/> Lights - Head-Stop	<input type="checkbox"/> Safety Eq. - Spare Seal Beam
<input type="checkbox"/> Brake Accessories	<input type="checkbox"/> Lights - Tail-Dash	<input type="checkbox"/> Springs
<input type="checkbox"/> Brakes	<input type="checkbox"/> Lights - Turn Indicator	<input type="checkbox"/> Starter
<input type="checkbox"/> Carburetor	<input type="checkbox"/> Mirrors	<input type="checkbox"/> Steering
<input type="checkbox"/> Clutch	<input type="checkbox"/> Muffler	<input type="checkbox"/> Tachograph
<input type="checkbox"/> Defroster	<input type="checkbox"/> Oil Pressure	<input type="checkbox"/> Tires
<input type="checkbox"/> Drive Line	<input type="checkbox"/> On-Board Recorder	<input type="checkbox"/> Transmission
<input type="checkbox"/> Engine	<input type="checkbox"/> Radiator	<input type="checkbox"/> Wheels
<input type="checkbox"/> Fifth Wheel	<input type="checkbox"/> Rear End	<input type="checkbox"/> Windows
<input type="checkbox"/> Front Axle	<input type="checkbox"/> Reflectors	<input type="checkbox"/> Windshield Wipers
<input type="checkbox"/> Fuel Tanks	<input type="checkbox"/> Safety Eq. - Fire Extinguisher	<input type="checkbox"/> Other


BACK NEXT

On the last screen, you and your mechanic can sign off on the DVIR. Clicking the open field pops up a fill-in signature pad where you can sign your name. Complete the report by selecting “Save & Send”

The screenshot displays the 'WLI DVIR' application interface. At the top, a black header contains a back arrow and the text 'WLI DVIR'. Below this, a grey header area contains the title 'PRE TRIP - DRIVER'S VEHICLE INSPECTION REPORT' and the subtitle 'As required by the Federal Motor Carrier Safety Regulations for Commercial Drivers'. The main content area is dark grey and contains a checked checkbox labeled 'Condition of vehicle is satisfactory'. Below this, there are input fields for 'Driver Name', 'Driver Signature', and 'Date'. A white signature pad overlay is positioned in the center, titled 'Driver Signature', and contains a handwritten signature. The signature pad has three buttons at the bottom: 'CLEAR', 'CANCEL', and 'OK'. At the bottom of the application, there are two buttons: 'BACK' and 'SAVE & SEND'.

2.2.4 Inspection State

If you entered an “ON DUTY – not driving” state other than Pre-Trip or Post-Trip Inspection (eg Yardwork), and still need to enter an Inspection into DVIR, then you will find a new option listed when you click the Big Green Button, “Inspection”.



Clicking “Inspection” will give you the screen below, where you can choose a “Pre trip” or a “Post trip” inspection state. Both options will launch DVIR.


The screenshot shows the "Driver Log" interface for Turnkey Trading LLC on 2/12/2017 at 12:29 PM EST. The driver is Carlos Landrian. The summary table shows:

	ON DUTY TILL NOW	DRIVING BALANCE
CYCLE	98:44	-28:44
SHIFT	98:44	-84:45

The chart below shows a time axis from MID-NIGHT to 11 PM. The "ON DUTY (NOT DRIVING)" state is active from 12:27 to 0:00. The "DRIVING" state is active from 0:00 to 0:00. The "TOTAL HOURS" column shows 00:00 for OFF DUTY, SLEEPER BERTH, and DRIVING, and 12:28 for ON DUTY (NOT DRIVING). An "Inspection" dialog box is overlaid with options for "Pre trip", "Post trip", and "Cancel".

2.3 Entry View


In order to view more entries at once you can expand the view screen by holding and dragging up on the chart, to see this view of the main page. Each of these status changes can be clicked on for a more detailed view. See the next page for an example of this.



2.4 Extended View

Tapping a status change shows additional information about the change. The chart has a little red arrow which shows where the status change occurred. The additional information includes details such as entry creation date, location, and any other fields added by the driver at the time of the change.

With your finger on the chart, you can drag down to return to the main view of the screen.



2.5 Getting To Other Screens

Clicking on **Driver Log** at the top center of the screen you can select from several other screens and see

- **Cycle Report**
- **Calendar**
- Toggle on and off **Deleted Entries**
- And the **About** section

There is also the option to change your **PIN** from this dropdown. Please be careful and only change your **PIN** if you are sure you can remember the new **PIN**.

Each of these screens are explained further below.

The screenshot shows the 'Driver Log' application interface for Turnkey Trading LLC on 2/12/2017 at 12:29 PM EST. The interface is divided into several sections:

- Header:** Turnkey Trading LLC, 2/12/2017 12:29 PM EST, Driver Log
- Navigation Menu:** Driver Log, Cycle Report, Calendar, Change PIN, Switch Driver, Show Deleted, Info, About
- Log Grid:** A grid showing time intervals (10, 11, NOON, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11) and activity levels (OFF DUTY, SLEEPER BERTH, DRIVING, ON DUTY (NOT DRIVING)). A red arrow points to the 'ON DUTY' bar at 12:01.
- TOTAL HOURS:** 00:00, 00:00, 00:00, 12:29
- Driver Information:** 2/12/2017 12:25 PM EST, Seq Num: 43, Status: Active, Odometer: 42000, Location: Miami, Florida, Longitude: -80.4149825, L...
- About:** Tractor:10, Trailer:11, Driver: License Expiration:15 Aug 2017, Serial:5b861a39-rotohos.wlius.com
- Activity Log:**
 - 2/12/2017 12:24 PM EST LOGOUT
 - 2/12/2017 12:23 PM EST LOGIN - Long Haul
 - 2/12/2017 12:21 PM EST LOGOUT
 - 2/12/2017 12:20 PM EST LOGIN - Long Haul

2.6 Violations

You will see red lines in the graph when you were in **VIOLATION**. You can click on **VIOLATION** in the log list below the graph to see details about the violation.

2.7 Submit Button – ELECTRONIC SIGNATURE

At the end of every shift, make sure you submit your log. Clicking the submit button acts as an electronic signature, verifying the accuracy of your logs. This is just like signing your current paper logs.

Confirm your submission on the screen that follows.

The screenshot displays the 'Cycle Report' interface for Turnkey Trading LLC on 2/12/2017 at 12:31 PM EST. The interface includes a grid for tracking time spent in various states: OFF DUTY, SLEEPER BERTH, DRIVING, and ON DUTY (NOT DRIVING). A red arrow points to a 'Click Here to Submit Daily Log' button. A confirmation dialog is overlaid on the screen, titled 'Submitting log (today 12 Feb)', with the instruction: 'Click on the Submit button to acknowledge that you verified your log and it is correct.' The dialog also shows a PIN field with '2014' entered and 'Cancel' and 'Submit' buttons. Below the dialog, a list of log events is visible, including LOGIN - Long Haul and LOGOUT events.

MID-NIGHT	1	2	3	4	5	6	7	8	9	10	11	NOON	1	2	3	4	5	6	7	8	9	10	11	TOTAL HOURS
OFF DUTY												0:00												00:00
SLEEPER BERTH																								00:00
DRIVING																								00:00
ON DUTY (NOT DRIVING)																								12:31

Submitting log (today 12 Feb)

Click on the Submit button to acknowledge that you verified your log and it is correct.

PIN 2014

Cancel Submit


2/12/2017 12:27 PM EST
2/12/2017 12:27 PM EST
2/12/2017 12:25 PM EST
2/12/2017 12:25 PM EST
2/12/2017 12:24 PM EST LOGOUT
2/12/2017 12:23 PM EST LOGIN - Long Haul
2/12/2017 12:21 PM EST LOGOUT
2/12/2017 12:20 PM EST LOGIN - Long Haul
2/12/2017 12:20 PM EST LOGOUT
2/12/2017 12:19 PM EST LOGIN - Long Haul
2/12/2017 11:18 AM EST LOGOUT

2.8 Program Bugs or Errors

It is important to submit a log every time your Driver Log application has a problem. See Section 6 on sending logs for instructions on how to do this.

You can help further by taking a screenshot to include with your log. Taking screenshots can change from device to device, but with most Samsung devices, you can take a screenshot by holding on the power button and home button of the tablet at the same time for five seconds (until the screen flashes). The power button can be found on the top of the right side of the tablet, and the home button is the big button on the front. Submitting the screenshot will be explained further in Section 6.

2.9 External Devices/BlueLink





1. When in settings go to “External Devices”
 - a. If you have a Piccolo Plus with WIFI select “Attach to Piccolo”
 - b. If you use a BlueLink dongle or a Piccolo STX with Bluetooth select “Attach to BlueLink unit”
2. If you selected BlueLink then you have the option to limit the communication:
 - a. between your device to any BlueLink or to a specific BlueLink if you select "Limit BlueLink Connection" ON, and then click on BlueLink ID and enter the specific BlueLink ID of a specific truck (this is the equivalent of selecting SSID when using WIFI)
 - b. If the "Limit BlueLink Connection" is not ON then DriverLog will link with the first BlueLink is connecting to, so if there are a few trucks one next to the other it could link with any truck.

2.10 Canada HOS

To enable automatic toggling between US and Canada rules, the setting has to be enabled (please see screenshot to bottom left). Once enabled the switch can be automatic based on GPS or it can be manual depending on how you set the settings. To manually switch in the application, please see the screenshot to the bottom right.

Operationally, the US and Canada settings are the same, except when in Canada there are different rules that DriverLog must calculate. DriverLog does this automatically and can work on a 7-day or 14-day cycle depending on the settings. However, the cycle report display is always 14 days.




3 Cycle Report

The **Cycle Report** is like a combination of the **Driver Log** screen, and the **Calendar** screen. On the **cycle report**, you can see all of your status changes for the last week and toggle which day's history you want to see for that time period.

There is also a detailed view of your **Cycle/Shift balance** with breakdowns for **ON DUTY – NOT DRIVING**, **DRIVING**, and **ON DUTY** (total) statuses.

“**ON DUTY**” is the sum of “**ON DUTY – NOT DRIVING**” and “**DROVE**”. “**DRIVING BALANCE**” is the total remaining time until you hit your 60 or 70 hour **ON DUTY** limit

(as defined by your Fleet Manager) for the **CYCLE** and 11 hour **DRIVING** limit for the **SHIFT**.




3.1 Cycle Reset

You can reset your cycle if and only if you have been off duty for 34 hours. This cycle reset is named, the 34-hour Off Duty Cycle Reset. Driver log keeps track of this for you and if you have been OFF DUTY for 34 hours, it will show you the following pop up to reset your cycle.

If you don't see this pop up, you can also click the "Tap to Reset Cycle" button to produce the pop up

4 Calendar

The calendar screen is where you can see a history log of all status changes.



By clicking on “Select Date”, you can select a time you wish to toggle in the history log view. Simply click the day you want to display on the **Calendar**.

The screenshot shows a mobile application interface for a driver's log. At the top, the status bar indicates the time is 1:50 PM and battery is at 19%. The app header shows 'Turnkey Trading LLC' and '2/12/2017 01:50 PM EST'. The main title is 'Calendar'. A 'Select Date' dialog is open, displaying a calendar for February 2017. The calendar shows days 1 through 28, with days 8, 9, 10, and 11 highlighted in yellow. Below the calendar, a log of events is visible, including 'LOGIN - Long Haul', 'LOGOUT', 'MALFUNCTION LOGGED', 'LOGIN - Long Haul', 'LOGOUT', 'SUBMIT', 'ON DUTY - not driving', 'OFF DUTY', and 'DATA DIAG LOGGED'. The log also shows a 'TOTAL HOURS' column with values like '00:00' and '13:50'.


5 Edit

Driver Log version 12.8 and newer use the easy edit described below. If you are using an older Driver Log, please ask for an older manual. Thanks.

5.1 Easy Edit

The easy edit is an “inline” edit. This means edits take place in the line where they are meant to go. So, if you need to add an event to some time at the end of yesterday, such as, right before your OFF DUTY event, you would go to that OFF DUTY event, press and hold there, and select from a pop-up screen: Add event before OFF DUTY. A new pop up would appear with your event choices and you can select the appropriate event.


As you can see in the screenshot, there is also the option to edit the already existing event, or to add an event before/after, or delete the already existing event. Simply select the option appropriate to your case and choose the corresponding action.



5.2 Edit Existing event

If you need to change an already existing event, find the event in your calendar, press and hold the event, and click “Edit [EVENT NAME]”. This will present you with a dialog box much like when you are creating a new event.


In the example below, I am editing my Off Duty entry to five minutes earlier. I did this by tapping the “Change” button next to time and selecting my new date and time. After completing my changes, I would click “OK” and the new changed time would appear.




5.3 Add entry before/after event

If you need to add an entry before or after an already existing event, press-and-hold on the already existing event and select “Add event [before/after] [EVENT NAME]”.

For this example, I will add a Post-Trip Inspection entry before my OFF DUTY. So, after clicking “Add event before OFF DUTY”, I will see the screen below, where I will click “ON DUTY – not driving”




Next I select the “On Duty job” and change the start time, set the odometer, city, state, and fill in the addition info as seen below. All of this should be exactly the same as if you were creating the event in the correct order the first time around. The only difference is that you have to set the start time. When you are done, you can click “OK” and you should see your new entry in the list. If you are adding an event to a previous day, you may have to go to the Calendar screen and select that day to see the new entry.



5.4 Delete entry

If you need to delete an entry, press and hold on the entry, and click “Delete”. A confirmation screen may appear, like below. Tap “Confirm Delete” to complete the deletion of the entry. If you are having trouble finding the entry you want to delete, please go to the Calendar screen and choose the day where the entry should have occurred.



6 Info Button

The info button in the dropdown under “Driver Log” (see bottom left screenshot) opens the screen shown in the bottom right screenshot. This is a snapshot of your daily general info. Click on **JBUS DATA** to see information about your current location and engine information (loaded from a BlueLink or Piccolo device).

NOTE: In some trucks, especially older models, there is a discrepancy between the odometer from the JBUS, that is your truck’s computer, and the odometer on your truck’s dashboard. The Driver Log odometer entry is based on the automatic entry from the odometer field on the JBUS. In the case that an officer is questioning the validity of the distance you have travelled, by pressing on current JBUS Data, the tablet will display the current odometer reading from the JBUS and the GPS Location and RPM. This will show you the discrepancy mentioned here.

The image shows two screenshots from a mobile application. The left screenshot is a vertical menu with the following items: Driver Log, Driver Log, Cycle Report, Calendar, Switch to Canada, Change PIN, Switch Driver, Show Deleted, Info (highlighted with a red box), and About. The right screenshot shows the 'Info' screen for Driver Carlos Landrian (ID: Carlos). The screen is divided into several sections: a top header with the driver's name and ID, a 'GENERAL' section with carrier and office information, a 'JBUS DATA' section with current location and engine data, a 'DUTY DRIVING' section with a table of on-duty and driving times, and a 'TOTAL HOURS' section with a table of hours for the current day. The 'Info' button in the left menu is highlighted with a red box.

ON DUTY	DRIVING
TILL NOW	BALANCE
100:08	-30:08
100:08	-86:08

	8	9	10	11	TOTAL HOURS
ON DUTY					00:00
SLEEPER BERTH					00:00
DRIVING					00:00
ON DUTY (NOT DRIVING)					13:52

7 About

This screen tells you the version number of the app, and gives you the ability to send logs.

7.1 Sending Logs


Click **“Send Problem Report”** to send logs.

On the screen , please fill out the Problem Description and a brief explanation of How the issue occurred. Then click “Submit”.


8 WIFI

If you are having trouble connecting to the **WIFI**, you are in the right place.

Drag down from the very top of the tablet, near the middle. **You may need to do this twice** in a row to get the menu shown below. Next, **press and hold your finger** on “**Wi-Fi**” for **3 to 5 seconds**.




Make sure **Wi-Fi** has a green bar next to it, like below in the **Network Connections** pane on the left of the screen. **If it doesn't, slide the bar to make it green.**
Next, **tap your WI-FI Network name** (mine is R7KBD)




Now **type** in the **password** to the **WI-FI** on your tablet **using** the **pop up keyboard** that should appear on the screen. If you don't have the password, ask your Fleet Manager or Dispatcher. Now **click** "**Connect**".


You can return to the app you were using before by **clicking the home button** on your tablet and navigating to and **clicking on the app icon**.



If you don't get prompted for a password, but get a page like the one below, then you are already connected to the **WIFI**.



If you get a page like the one below, when you **click** on your **WIFI Network name**, then the password has already been entered, but the **WIFI is not in range** (that is, the signal is too far away, or not on at all).



To ensure that you always reconnect to the WiFi when you come in range, please click the tile icon indicated in the screenshot below and select “Advanced”



← Click here

NETWORK CONN...


Wi-Fi




Bluetooth




Airplane m..




Data usage



Location




More netwo..



CONNECT AND S...

Nearby dev..



Wi-Fi

WI-FI NETWORKS

6T35F
Not in range

FIOS-LEPVF
Not in range

Office
Not in range

R7KBD
Not in range

WLI04
Not in range

WLI3050
Not in range

WLI827843
Not in range

WLIcd826777
Not in range

WLIcd826778
Not in range

WLIorion
Not in range

+ Add Wi-Fi network

- Advanced
- WPS push button
- WPS PIN entry
- Help

As indicated on the screen below, click Wi-Fi Timer

The screenshot shows the Windows Settings application with the 'Connectors' tab selected. The left sidebar lists various network-related settings, including Wi-Fi, Bluetooth, Airplane mode, Data usage, Location, and More network settings. The main pane displays the 'Wi-Fi > Advanced' settings. The 'Wi-Fi timer' option is highlighted with a red box, and a red arrow points to it with the text 'Click here'. Other settings shown include 'Network notification' (checked), 'Sort by' (Signal strength), 'Keep Wi-Fi on during sleep' (Always), and 'Always allow scanning' (checked). Below these are sections for 'Install certificates', 'MAC address' (8C:BF:A6:99:01:6D), and 'IP address' (fe80::8ebf:a6ff:fe99:16d, 192.168.1.214).

Now click the check boxes for “SET START TIME” and “SET END TIME” and then adjust the values to 12:00 AM for the start time and 11:59 PM for the end time. Then click “Done”. You should now automatically reconnect to WiFi when in range.

