


Turn on your phone or tablet's GPS and Bluetooth capabilities, Connect your hardware to your truck's ECM or OBDII Port.

If you are using the "GEAR" hardware, a flashing green and red light should appear on the front edge.

User Manual



Using the login information you received in the Welcome Email

- Username or Email Here
- Password Here
- ▲ If this is your first time logging in, please accept Terms of Service and Application Permissions



Chose the Truck You Are Using Today You Can Search by Vehicle ID or VIN

Is this the correct truck?

If so Select Accept

If so Select Decline

Continue Without a Vehicle to access logs without selecting a vehicle.















For added safety to the driver, a password will be needed to leave this screen to ensure that an inspecting officer only sees what they need to see.

- DOT Inspection
 Instructions Found Here
- To Send Logs Select Send Logs to DOT
- Log History
 Shows PDF versions of daily logs





















13

How to report malfunctions and recordkeeping procedures


- Note the malfunction of the ELD and provide written notice of the malfunction to the motor carrier within 24 hours
- Reconstruct the record of duty status for the current 24-hour period and the previous 7 consecutive days, and record the records of duty status on graph-grid paper logs
- Continue to manually prepare a record of duty status until the ELD is serviced and brought back into compliance
- 4. Compliance Malfunction Codes:
- · PWCM Power
- ESCM Engine Synchronization
- TCM Timing
- · PCM Positioning
- · DRCM Data Recording
- DTCM Data Transfer
- O Other




Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELDID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT#	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odom- eter	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	




Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELDID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT#	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odom- eter	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	




Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELDID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT#	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odom- eter	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	




Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELDID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT#	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odom- eter	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	




Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELDID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT#	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odom- eter	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	



Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELDID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT#	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odom- eter	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	



Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELDID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT#	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odom- eter	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	



Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELDID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT#	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odom- eter	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	