



3202 McKnight East Dr Pittsburgh, PA 15237

info@fiveeld.com

267-526-0466

USER'S MANUAL

TABLE OF CONTENTS

03 - 06

APPLICATION GUIDE

07 - 08

USING ON THE ROAD


09 - 10

REVIEW ELD LOGS

11

ELD MALFUNCTIONS

APPLICATION GUIDE




01

Log in to application using your username and password.

If you don't have a Five ELD account, please, contact your carrier.

If you don't remember your password, contact to your carrier.



02

Your tablet with Five ELD application automatically scans for ELD.

When you log in to your Five ELD account, the app starts scanning for available ELD devices automatically.

And the ELD device lights green, when it is ready to use.




ELD devices

Make sure your vehicle engine is turned off. If the engine is on, please turn it off and turn the key to the “**Off**” position before connecting ELD device.

Once plugged in, the device will start syncing with the engine control module [ECM] and Five ELD application on the tablet.


Then get the tablet provided by fleet and turn it on. Tablet should automatically start application.



03

You should choose your ELD.

Once the scanning is complete, select your ELD device from the displayed list of results.




04

If the ELD is connected to vehicle, you can see green icon on the top left corner of the dashboard.


If it is not connected, the icon stays red with "ELD not connected" text.

USING ON THE ROAD



Once you have connected your mobile device to ELD, your driving time is automatically recorded.


When your vehicle starts moving and reaches the speed of at least 5 mph, your duty status is automatically set to **“Driving”**. If the speed of your vehicle goes less than 5 mph, your duty status changes to **“On Duty”**.



01

Choose a status in the main window based on your current situation.

From the statuses in the main window, select "Off Duty", "Sleep", "On Duty" depending on your situation.




02

Fill out location field and put remarks

For example "Pre-trip inspection" or "Coffee break" (if the location field is left empty, it will be automatically set).


REVIEW ELD LOGS



Follow the given guidelines to show your records to the officer

Tap **“Menu”** icon on the top left corner and select **“DOT report”**.


Tap **“Begin inspection”** and show your electronic logbook’s eight-day summary to the officer.



01

Follow the given guidelines to show your records to the officer

Tap "Send ELD Output File to DOT".



02

Transfer ELD records to authorized safety officer for inspection

Afterwards, you should choose one of 2 available options through radio buttons: "**Web service**" or "**Email**". As soon as you select the necessary method, write comment down below. After filling out the form, press the "Send" button.

395.22 Motor carrier Responsibilities

A motor carrier must ensure that its drivers possess onboard a commercial motor vehicle and an ELD information packet containing the following items: An instruction sheet for the driver describing ELD malfunction reporting requirements and recordkeeping procedures during ELD malfunctions. The following instructions are in accordance with the guidelines set forth in 395-34

The following instructions are in accordance with the guidelines set forth in 395-34

Five ELD will monitor and report malfunction data based on section "4.6 ELD's Self-Monitoring of Required Functions", table 4:

- P** – "Power compliance" malfunction,
- E** – "Engine synchronization compliance" malfunction,
- T** – "Timing compliance" malfunction,
- L** – "Positioning compliance" malfunction,
- R** – "Data recording compliance" malfunction,
- S** – "Data transfer compliance" malfunction,
- O** – "Other" ELD detected malfunction.



3202 McKnight East Dr Pittsburgh, PA 15237

info@fiveeld.com

267-526-0466



If your issue cannot be resolved right away, please feel free to reach out to our support team. They are available 24/7 and are ready to assist you in any situation.