![CloudELD logo]

A Complete Solution for Trucking Companies

TABLE OF CONTENTS

1.Download the CLOUD ELD app for Android devices

1. Search for "CLOUD ELD" in Google play store for Android phones and Tablets

Tap on Install to download the app

2. Open Cloud ELD App

Tap on the Cloud ELD icon to open app

3. Login to Cloud ELD App

Log in with the credentials provided by your motor carrier.

4.Connect your mobile device to CLOUD ELD app

On the main logs screen,Tap on the vehicle connection status icon on the top right to connect with the vehicle's ELD

Connect your Mobile device to the CLOUD ELD app

Your device will be automatically attempt to connect to the Vehicle's ELD using bluetooth

A green icon will appear at the top right of the main logs screen to indicate a successful connection

5. Home Screen

Home screen shows current duty status in the main circle and next break, driver time, shift time and total cycle time left.

6. Change Duty Status

To change duty Status, Tap on the current status in home screen which is highlighted in red color.

Change Duty Status

Tap the new duty status that you want. The Home screen appears with the new duty status that you selected.

.

7. Personal Conveyance Status

This is a special driving category that might be provided by your carrier. This duty status counts as Off Duty

8. Yard Moves Status

This is a special driving category that might be provided by your carrier for moving material around a yard or via private driveways.

9.Drive Time Mode

When the vehicle is moving more than 5 mph, the duty status automatically changes to Drive Mode.

When the vehicle stops, you will get following option to change the duty status.

10.Insert Driver's Duty Status

Click on this Icon 📊 in Home screen and in Graph screen, Click on + Icon on the bottom which is highlighted in red color to insert duty state


In the following screen select the status and enter Start &End Time and Remarks information.

11. View / Edit Driver's Duty Status

On the Logs screen, click on the edit icon on driver's duty status record.


On the edit duty status screen, you can edit start, end time, location, and remarks..

12.HOS Violations

In Graph screen if any violations will show those HOS in red color.


Violation screen will show list of violations for the specific 24 hours period.

☁ 13.Co-Driver Login

Click on the Co-Driver icon which is marked with red circle below and enter Username and Password provided by carrier

100% 06:23

K

Kris Pittman
kris@yahoo.com

Co-driver Login

USER NAME

vinc

PASSWORD

••••

CANCEL | LOG IN

More

Share

Help & Feedback

About

14. Requested Motor Carrier Edits

Any Driver's duty status records edits requested by motor carrier to driver will show on click on 🚗³ top right corner of the Home Screen

15. Unidentified events

Any events created under 'Unidentified' driver profile, on click on this icon 🚗² will show all the list of Unidentified events in the device.

Click on FORM tab to enter all the required information about the trip distance and shipping documents.


Driver | Co - Driver
Kris | Vincent

Load# | Commodity
2456 | grain

Origin | Destination
West Sacramento,CA | San Francisco,CA

| Truck Number | Start Odometer | End Odometer | Distance | + |

GRAPH   LOGS   VIOLATION   FORM   DVIR

🚚 17. DVIR

Click on DVIR Icon on the E Log screen, it will allow you to create Driver Vehicle Inspection Report.

Fill out the following information in General with Inspection Type , Vehicle Tabs and Signature :

If any truck / trailer defect enter under "Vehicle" tab

On Signature tab, electronically sign the DVIR Record.

18.Certify Logs

Click on Certify icon to certify electronically all information entered is correct and true.

19. DOT Inspection Mode

Click on the menu icon on the top left and select DOT Inspection mode menu. **DOT Inspection Mode**

20.Data Transfer

Click on ➤ icon in DOT Inspection screen on the top right corner to send the output file through email or web services.

21. Data Diagnostic Events

If an inconsistency with data in device, it will show data diagnostic event [D] icon in home scree, on click it will show all data diagnostic events.

22. Malfunctions

If any malfunction in device, on Home Screen top right will appear [M] icon, on click it will show all malfunctions in the device.

23. Settings

It allows you to manage the Driver, Carrier, Cycle Type and Signature as per required.

i) Driver
Here you can update the Driver Phone, Email, Trailer and Turn on/off the day mode.

ii) Carrier
It allows you to view all the carrier information.

iii)Cycle Type

It allows you to view the Time Zone and Cycle Type after creating the Log Cycle.

iv)Signature

Here the Driver can update the E-Signature and save it.

CONTACT DETAILS

www.cloudeld.com

(916) 945-2894

support@cloudeld.com