


Contents

Installing the Hardware in your vehicle	4
Getting hardware connected to the engine	
Getting hardware connected to App	
Getting Setup on the Mobile Application	10
Downloading mobile app	
Connecting to ELD Device	14
???	
Using the Mobile Application	17
Recording your HoS with the ELD	
Change your current duty status	
Insert past duty status	
Create a Daily Vehicle Inspection Report (DVIR) Sign your logs	
Useful Tools	30
Find errors in your logs	
Let an officer inspect your logs	
Email fax your logs	

Installing the Hardware in your vehicle



Next, please locate the engine diagnostic port. Generally this port is found in 1 of 4 locations;






If you're having trouble locating this port please refer to your vehicles owners manual




Connect the cable and the box that are included in the package.



Press until the clip snaps in place.


(Just until the 10 comb like pins are no longer visible. Excessive force is not necessary)





Attach the cable to the vehicle diagnostic port. Once you've attached the device to the diagnostic port, twist the collar clockwise to lock into place.

If you have a vehicle with a connection type other than the circular 9 pin: plug in attachment






Find a safe place for the box to set. Be sure the "THIS SIDE UP" is visible.



Before mounting the device please be sure to clean the area you'll be adhering the device to. Let this area dry after cleaning.



Getting Setup on the Mobile Application



Once the mobile application is downloaded, and opened you will either need to login or sign-up.

- 1. Signup goo.gl/jZuw78
- 2. If you're part of a fleet you'll need to ask your dispatcher to add you as a driver.



Open Super Dispatch App


- 1. Type email
- 2. Type password (or use Super Link)
- Please select to share locations "Always Allow"

Note:

ELD device is responsible for location services information when connected, so if you chose "Don't Allow" this will not effect your FMCSA compliance.




Next you will need to open the HoS tab.




If you want to learn more about Super Dispatch ELD, please tap on Learn More button from this screen, otherwise you can dismiss this step by tapping Dismiss button

Select Home Terminal Time Zone, then tap Done



Select *Specify a vehicle*






You need to input your vehicle information, when completed select "Done".



Connecting to ELD Device



Connect to ELD



Your ELD device should match up with the last four digits of the MAC address on the back of your hardware proceeded by PT30.







If you do not find your device in the list, please contact your dispatcher or Super Dispatch Support:

support@mysuperdispatch.com

Confirm you'd like to connect to device.



Once your connect you can back out to the HOS home screen.






If you're connected you will see a green ELD logo indicating this.

Alternatively, it will say not connected.



Once you're connected on the Mobile application you should see a green light on the ELD hardware connected to your vehicle.


You're all set!



Using the Mobile Application




First you should download the Super Dispatch mobile application. While this is downloading and installing, you can begin the hardware installation.



iOS:


- Open App Store on your iPhone
- Search for "BOL App for Car Haulers (ePOD)"
- GET
- Open






Android:

- Open Google Play Store
- Search for "BOL App for Car Haulers (ePOD)"
- Download
- Open







Once you've connected to the ELD device your drive time will automatically be recorded.

- 1. If the vehicles engine is on the mobile device will be in "On Duty"
- 2. Once the vehicle exceed 5mph the mobile device will you change your status to "Driving"



- 3. Once the vehicle speed reaches 0mph you will be able to change the status to "Off Duty", "On Duty" or "Sleeper Berth".
- 4. If the vehicle slows down to 0 mph for 5 consecutive minutes without any user interaction a pop-up window will appear asking if you want to change your status.



If nothing is done, the device will re-designate the status on the Super Dispatch mobile application from "Driving" to "On Duty"




Editing Hours of Service


1. If you need to edit past duty status you can do this by simply selecting the day



Tap "Add New Record"



Tap status you want to add.



····· 🕏 9:41 AM Add New Record Start Time 30 PM

Tap "Start Time" to add beginning of status change and press green check.

Tap **End Time** to add the end of the status change and press green check.


Add location.

Add notes.

It's important to add detailed notes on edits so that records show why records have been edited.

Tap Save in the top right.

2. If you need to edit an existing log you can do this by tapping on the specific log



You can change Start Time by tapping it and set the time.





Do a DVIR (Daily Vehicle Inspection Report)


1. Select the day you want to do an inspection for



2. Select "DVIRs" in the top right corner




Tap "Add New DVIR"




1. Step one


- 1. Tap "Inspection Time" field and adjust the time to when DVIR was completed. Once completed tap green check.
- 2. Add location of inspection
- 3. Add Odometer reading at time of inspection
- 4. Tap Next



- 2. Step two
 - 1. Add Truck Number
 - 2. Tap "Add/Remove Truck Defects"
 - 3. Add Trailer Defects
 - 4. Tap "Add/Remove Trailer Defects"




- 3. Step three
 - 1. Select Defects Corrected or Defect Need Not Be Corrected
 - 2. Get Driver Signature / Mechanic Signature
 - 3. Tap Done







Submit A Report


1. To submit a report, please tap Report button on the top right of the screen









3. If you want to include attachments to your report, tap on Include Attachments



4. Select the attachments that you need by tapping on it and tap Done below screen



5. Here you can see the amount of included attachments




Tap Send Report button to send the report

Useful Tools


Finding Errors in your logs

1. A red exclamation indicates (i) a warning on your logs, and should be addressed.



2. Hours Of Service Violations

1. A red line on your graph indicates you have an existing violation that should be addressed.



If you want to edit the log with violations, go to the page 17.



- superdispatch.com
- Mello@mysuperdispatch.com
- 4436 State Line Road Kansas City, KS 66103