

REGULOG ELD

Welcome to the ELD Essentials Quick Start Guide

This manual will help you get started with your Electronic Logging Device (ELD).

■ **Install ELD Hardware**

Firstly, identify the ECM (diagnostic) port in your vehicle. Depending on your vehicle type, connect the ELD hardware using the appropriate 6-pin, 9-pin, or OBDII cable provided. Mount the device on your dashboard to ensure visibility.

■ **Download the Mobile App**

Visit your device's app store, search for the ELD app, and complete the installation process.

■ **Log into the Mobile App**

Enter the login credentials supplied by your fleet manager. After logging in, select your vehicle from the provided list.

■ **Manage Duty Status**

Effortlessly toggle between different statuses through the app's intuitive interface. Driving time is recorded automatically.

■ **Certify Logs**

Regularly sign and certify your logs to comply with regulatory requirements.

■ **Create DVIRs**

Regularly generate Vehicle Inspection Reports to keep your vehicle in optimal condition.

■ **HOS Violations and Warnings**

Receive instant alerts about potential Hours of Service (HOS) violations.

Off Duty



Sleeper



Driving



On Duty



■ Supported Data Transfer Mechanisms

You can transfer your logs using FMCSA-approved telematics methods:

- Web Service: Sends logs securely to FMCSA servers.
- Email: Sends encrypted log files to FMCSA by email.

■ Transfer Logs

When requested by an officer, follow these steps to send logs:

- In the ELD app, tap “DOT Inspection” in the menu.
- Choose Web Services or Email.
- Input the file comment provided by the officer.
- Tap send button. A confirmation message will appear once the transfer is complete.

Send 8 Logs

COMMENT

123456

DATA TRANSFER TYPE

Web Service

SEND

- **Access the Online Portal**

Use your credentials to log into the portal where you can monitor compliance and vehicle performance.

- **Transfer Logs**

Easily send logs for a specific range of dates to the FMCSA officer during the DOT inspection.

- **“Yard Move” and “Personal Use”**

Allow/disallow "Yard Move" and "Personal Use" statuses to meet the unique operational needs of your drivers and fleet, ensuring compliance and efficiency.