

Table of Content



ELD Installations Connection

Install the TruckSpot Device in Your Vehicle	3-4
Install the TruckSpot App	5
Log in to the TruckSpot App and Select the Vehicle	6
Connect the TruckSpot App with Your Vehicle	7
Change Duty Status	8
Complete DVIR	9-1
Populate Log Form Data	12-14
Record Hours of Service	15
Inspect Logs	16
Data Transfer Procedure	17


Installation Connection




Install the TruckSpot Device in Your Vehicle

Firstly, it's important to install the device properly. Keep in mind that your engine should be off while doing this.

1. With the engine off, locate the diagnostic port inside the vehicle. It is located in one of the four places shown in the picture below.



2. Attach the device to the diagnostic port of the vehicle.




Installation Connection




3.

Once the device is installed, ensure the device is working properly, as evidenced by a green LED light blinking. The green light starts blinking after a GPS G Cellular connection is initiated.



4.

Securely mount your device in a location where there are no electrical components nearby. This will help prevent potential issues like device interference and GPS signal disruption. We recommend placing the ELD device in a visible area with a clear and unobstructed view of the sky, as shown in the image below.



IMPORTANT: Please follow the above-mentioned instructions. Otherwise, you risk ELD device interference and GPS disruption, creating problems with the signal. Do not put an ELD device under the dashboard under any circumstances.

Installation Connection



Install the TruckSpot App


1. For Android phones and tablets, download the [TruckSpot](#) app from the Google Play Store.



2. For iPhones and iPads, download the [TruckSpot](#) app from the App Store.



3. Open the [TruckSpot](#) App.





Installation Connection



Log in to the TruckSpot App and Select the Vehicle

Please read the login instructions in the email we sent you. If you don't have the login details yet or have forgotten them, please contact your carrier administrator.


1. Enter your login details and tap **LOG IN**.
2. Select your vehicle device from the discovered devices list.
3. After accepting the vehicle you will be prompted to the main Dashboard page.



Co Driver Login

There are two ways a co driver can login to the app:


- 1) The driver can click the burger menu icon on the dashboard screen and then on the sidebar , the driver can click on the CO Driver login to login to the app with the role of co driver.
- 2) Other than sidebar , the driver can also login as a co driver by clicking the add to co driver section under Shipment & Payload.



Login Dialog : The driver will be prompted with this login form and upon entering the correct co driver credentials , the driver will be able to login inside the app

Co Driver Login

After the successful login , both the drivers will be able to see their own profile and their own driving separately



Installation Connection




Connect the TruckSpot App with Your Vehicle

After successfully logging in and selecting the vehicle, the Dashboard page will open. On this page, you will see the Connection Button

1. Tap the **ON** to connect to your vehicle. The device will attempt to connect to the selected vehicle via Bluetooth. The button will change from red to orange to mark the pairing process.

! Please ensure that Bluetooth is enabled on your device before you connect to the **TruckSpot** app.



Installation Connection




Complete DVIR

After successfully logging in and selecting the vehicle, the Dashboard page will open. On this page, you will see the Connection Button


1.

From the DVIR view, tap Start Inspection.



If you are in Off Duty or Sleeper Berth status, you will be prompted to change to On Duty status. Pre-trip is selected by default.

Note: If this is your first ride, you won't see the list of previous inspections




Installation Connection




2.

Tap [Add/Remove Defect](#) under Vehicle Defects and review each item from the list against your vehicle.



3.

If you identify a defect, select the appropriate item from the list, enter a comment, and attach a photo. Then, tap [Save](#).



Documents update section



Select the [Trailers/Docs](#) button from your Dashboard to add the Trailers/Shipping Docs number.

Update Shipment
Set your current trip details

Shipping Number *
☰ 183737

Co-driver
No Co-driver ↓

Trailer Number
📄 201


Cancel Update

Shipping # :183737 Trailer # :201

Home 📄 📄 📄 ✎

Populate Log Form Data

Select the [Trailers/Docs](#) button from your Dashboard to add the Trailers/Shipping Docs number.



The image shows a smartphone screen displaying the 'Update Shipment' form. The form is titled 'Update Shipment' and has the subtitle 'Set your current trip details'. It contains three input fields: 'Shipping Number *' with the value '183737', 'Co-driver' with the value 'No Co-driver', and 'Trailer Number' with the value '201'. At the bottom of the form are two buttons: 'Cancel' and 'Update'. Below the form, a summary section shows 'Shipping #: 183737' and 'Trailer #: 201'. The bottom navigation bar of the app is visible, showing icons for Home, a clipboard, a list, a document, and a pencil.

Update Shipment
Set your current trip details

Shipping Number *
183737

Co-driver
No Co-driver

Trailer Number
201

Cancel Update


Shipping # :183737 Trailer # :201

Installation Connection



Trailers/Shipping Docs are also available through the [Logs](#) folder. Here are the steps you should follow:

1. From your [Dashboard](#) view, tap the [Logs](#)
2. Select [Logs](#).
3. Tap the log at the top of the list.




Installation Connection



4.

Tap Other to see the [Trailers and Shipping Docs](#) field.





Record Hours of Service

1 When your vehicle reaches 5 MPH or greater, **TruckSpot** indicates that the vehicle is In Motion, and your duty status will automatically change to Driving.

2 When the vehicle stops (0 MPH), it's considered Stationary.

3 You can change your duty status by tapping the Driving and selecting another duty status.


4 If your vehicle remains Stationary for five minutes, you will be asked if you want to change your duty status. If you ignore this question, your duty status will be changed to On Duty.






Inspect Logs

When an officer asks for your logs, tap [Start Review](#) and the logs for the last seven days will appear on the screen.



Data Transfer Procedure


1. If the officer asks for the output file, tap **Transfer Data** to send the file via web service or email.



2. Select **Web Service** or **Email** transfer method.

3. When a DOT officer provides the Output File Comment, enter it in the text box.

4. Tap **Send**.



5. If the file was submitted successfully, you will receive a confirmation. If it was unsuccessful, you will receive the following message: "ELD Output File sending failed. Please try again or use a different Transfer Data method."

Malfunction & Diagnostic Events

ELD Malfunction Events (49 CFR Part 395 Appendix A §4.3.2)

When an M indicator appears in the app header, tap it to view the specific malfunction alert. The alert will display the malfunction type and code as listed in the table below. The driver must note the malfunction, continue to monitor, and notify the carrier in writing within 24 hours. If the ELD can no longer record HOS data accurately, reconstruct paper RODS for the current 24-hour period and the previous 7 days and continue on paper until the malfunction is resolved. The motor carrier must correct the malfunction within 8 days of discovery.

CodeMalfunction	TypePPower Compliance MalfunctionEEngine Synchronization Compliance MalfunctionTTiming Compliance MalfunctionLPositioning Compliance MalfunctionRData Recording Compliance MalfunctionSData Transfer Compliance MalfunctionOOther ELD Detected Malfunction
-----------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

ELD Diagnostic Events (49 CFR Part 395 Appendix A §4.3.2)

When a D indicator appears in the app header, tap it to view the specific diagnostic alert. The alert will display the diagnostic type and code as listed in the table below. Diagnostic events do not require switching to paper logs. Continue operating normally and report to your fleet manager promptly so the issue can be resolved before it escalates into a malfunction.

CodeDiagnostic	Event1Power Data Diagnostic2Engine Synchronization Data Diagnostic3Missing Required Data Elements Diagnostic4Data Transfer Data Diagnostic5Unidentified Driving Records Diagnostic6Other ELD Diagnostic
----------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


Driver Console

04:41:03

Live compliance and fleet status

● Disconnected

0 mph



Logs Processing

Add Remarks



Add brief notes to explain log entries, edits, or delays. Keep remarks clear, relevant, and accurate for compliance and inspection purposes.

Exceptions

Apply applicable HOS exceptions (e.g., Personal Conveyance, Yard Move) as per Federal Motor Carrier Safety Administration guidelines. Use only when conditions are met and add remarks if needed.

Add New Log

Manually create or correct duty status entries. Ensure all details (status, time, location) are accurate. All changes are recorded for compliance.





Are you still uncertain about anything?

If you are still experiencing any doubts or difficulties with the steps, please do not hesitate to contact us at 209-564-1009. We will be happy to provide you with all the necessary information.

Thank you for choosing [TruckSpot ELD!](#)



Phone : 209-564-1009

email: Support@truckspoteld.com

Web: truckspoteld.com