

ELD Components

Tablet

The tablet is used in the cab to serve as the digital hours of service logbook

It connects to the Transponder via a cable to allow driver login, logout, change duty status and backup logs to the Web Portal

Transponder

The transponder sends power and data from the truck to the tablet and sends data from the tablet to the web portal

Driver App

The Driver App is used on the tablet to display the driver hours of service journal, record duty status changes and serves as a compliant logbook for roadside DOT inspections

Driver Web Portal

This website stores a backup the hours of service logbook for six (6) months of log entries and allows the driver to add or edit log entries

Installation

Instructions

- 1) Connect the vehicle cable to the truck's diagnostic port (DLC) which is located in the driver foot well and the transponder
- 2) Connect the tablet cable to the transponder and tablet mount
- 3) Attach the tablet mount to the windshield, where allowable by law, or dashboard and attach the tablet to the mount
- 4) Mount the transponder on dashboard using the included adhesive pads and route the cable along the left side of dashboard and secure any excess cable with included ties

Maintenance

Tablet

In order to keep the tablet's software, maps and points of interest current, it should be periodically updated using the included USB cable connected to a PC.

- 1) Install and open the Garmin Fleet Updater app
- 2) Connect the tablet to the PC and click **Update**
- 3) Maps will download to the PC and tablet
- 4) Up to 10 tablets can be updated at a time

Driver App - Operation

Login

Attach tablet to mount and tap the ELD app icon on the home screen

Tap **Login** and enter your **DriverID** and **Password**

Login will fail if there is no cellular signal

Update Duty Status

Attach table to mount, tap **Duty Status** on dashboard, select a new duty status, add a comment if required and tap **Save**

*Personal Use (PC) used for Off Duty Not Driving
Yard Moves (YM) used for On Duty Not Driving*

View Logbook and Certify Records

Tap the current day graph grid on dashboard, then swipe right and left to view other days (up to 8 days)

Tap **Certify** at the top of the graph grid to digitally sign all duty status changes displayed for the current 24 hour graph grid

DOT Inspection

Tap **DOT Inspection** on dashboard to prepare for inspection

Swipe right and left for additional 24 hour periods

Transfer driving records to the DOT by tapping **Send to DOT** and enter a comment if desired

Tablet must be attached to mount in order to send records; transferred via web services and email

Shipments

Tap **Shipments** on dashboard to edit shipments

Tap **Add Shipment** and provide document no., start/end time and tap **Save**

Tap an existing shipment to edit the document no. start or end time and tap **Save**

Vehicle

Tap **Vehicle** on dashboard to edit vehicle and trailer

Tap **Vehicle No.** to edit vehicle no. or **Trailer No.** to edit the trailer no. and tap **Save** when done

Logout

Attach tablet to mount, tap on your **Driver Name** on dashboard and tap **Logout**

You are prompted to certify records upon logout

It is recommended to logout at the end of every shift

Driver App - FAQ

Automatic Duty Status Changes

An automatic duty status update will be made for the driver's logbook when the truck starts and stops moving as shown in the following chart

From	To	Reason
On Duty, Off Duty or Sleeper Berth	Driving	Traveling faster than 5MPH (8KPH)
Driving	On Duty	Truck is stopped for more than 5 minutes

Claiming Records

If truck is driven without a driver logged into the tablet, the system creates automatic driving records which should be claimed by the appropriate driver upon login

ELD Diagnostic Messages

If there is a malfunction detected, the app will show this notification in the status bar 

This indicates a fault in the ELD system and may require attention from your fleet manager

This event is noted in the hours of service logbook

Driver Web Portal - Operation

Driver Login

Login to DrivingLogs.com with your email

Then enter your **DriverID** and **Password**

View Driver Logs

Select date range and click arrow

Click on graph grid for details

Download Log

To download one graph grid, click the PDF link next to the graph grid

Add Duty Status

Click on the graph grid and then click **+ Event**

Select new Duty Status and start time, enter a comment and click **Save**

Edit Duty Status

Click on the graph grid and click on a Duty Status

Select new Duty Status, enter new start time, add comment or edit location as needed

Not all items are allowed to be edited

Update Email or Password

Click Settings and enter the new password or email and click **Save**

Your DriverID is unique and cannot be changed

Support Portal

If you have a question that isn't answered here, click on Support to visit the Support Portal to review frequently asked questions, training videos and download support documentation

If the answer your question isn't found on the Support Portal, please open a support ticket by clicking Contact

Troubleshooting

Transponder

Check the power connection and if it is connected, unplug and reconnecting the cable to power cycle the transponder

Driver App

If the app is not responsive or not functioning normally you should quit and restart the app by tapping the square button on the bottom and tap the X or swipe up or to the right